



DETAIL SANDER - T18S/DS - SPARE PARTS			
No.	Qty.	Name	Part Number
1	1	Housing	
2	1	Housing foot plate	
3	4	Suspension column	
4	2	Shock pad	
5	1	Dustproof switch	
6	1	Switch on and off dust cover	
7	1	785 Motor	
8	1	Motor flange	
9	2	Cross pan head screw m4x10 with spring pad	
10	1	Bearing 6000	
11	1	Gasket	
12	1	Connecting shaft	
13	1	Fan	
14	1	Gasket	
15	1	Bearing 6001	
16	1	Counterbalance	
17	1	Guide ring of dust	
18	1	Wool felt	
19	1	Oscillating bracket i	
20	1	Oscillating bracket ii	
21	1	Scaleboard	WP-T18/DS021
22	5	St2.9x6 black	WP-T18/DS022
23	1	Triangle plate	WP-T18/DS023
24	1	Soft pad	WP-T18/DS024
25	5	St2.9x9 black	WP-T18/DS025
26	1	Battery pack	T18S/BA4AM, T18S/BA5A
27	1	Electrode plate	
28	1	Dust bag	WP-T18/DS028
29	1	Dust bag framework	WP-T18/DS029
30	1	Suspension column	
31	9	St2.9x19 black	
32	1	St2.9x14 black	
33	1	Dust spout adaptor	WP-T18/S001
34	1	Base plate assembly - 23-24, 25 (x5)	WP-T18/TS034
35	1	Dust bag assembly - 28-29	WP-T18/TS035