

INSTRUCTIONS FOR:

# STUD REMOVAL AND INSERT SET

MODEL No: AK7231

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.




IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY. AND WILL INVALIDATE THE WARRANTY, PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE

## INSTRUCTIONS


- Do not use the stud removal set for any purpose other than for which it is designed.
- Keep the kit free from dirt and grime.
- Ensure your work area is tidy and free from hazards.
- Ensure the correct size spanners are used to avoid injury and damage to the set.
- WARNING: The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which can not be built into this product, but must be applied by the operator.

### 2. USE




#### 2.1 Stud Removal

- 2.1.1 Screw the stud remover onto the stud, ensure the stud is proud of the removal nut. Refer to fig.1
- 2.1.2 Using two spanners tighten the nuts (A,B) together.




2.1.3 Keep the spanner on the lower nut (A) and unscrew the stud



### Stud Insertion 2.2

- 2.2.1 Screw the stud into the insert nuts until it reaches the steel ball, fig.3.
- 2.2.2 Screw the stud into the stud hole, using the correct size spanner.



2.2.3 When the stud is screwed in securely, loosen the allen screw on the top of the nut with the allen key provided. The insert nut will now be able to be removed without loosening the stud.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.





Sole UK Distributor Sealey Group, Bury St. Edmunds, Suffolk.



**a** 01284 757500



www.sealey.co.uk

sales@sealey.co.uk