

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- **WARNING! DO NOT** use the sockets if damaged. Maintain the sockets in good condition and replace any that become damaged or worn.
- Ensure all workshop safety rules, regulations and condition are complied with when using the set.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Wear appropriate eye protection.
- ✓ The work area should be clean, well lit and free from unnecessary clutter.
- ✓ Keep children and unauthorised persons away from the work area.

2. INTRODUCTION

2.1. Drop forged Chrome Molybdenum steel sockets. Reverse spiral flutes are designed to bite down to provide maximum gripping power. Set comes complete with 8mm straight rod to knock bolt out after use. Supplied in carry-case.

3. OPERATION

Note: The set is only useful for bolts with a positive thread.

- 3.1. Select an appropriate socket and position it over the bolt to be removed.
- 3.2. Strike the socket with a hammer, thereby forcing it onto the bolt.
- 3.3. Use a manual wrench to loosen the bolt.
- 3.4. Use the rod provided to remove the bolt from the socket.

Item	Part No	Description	
1	AK728.10	BOLT EXTRACTOR	10mm
2	AK728.11	BOLT EXTRACTOR	11mm
3	AK728.12	BOLT EXTRACTOR	12mm
4	AK728.13	BOLT EXTRACTOR	13mm
5	AK728.14	BOLT EXTRACTOR	14mm
6	AK728.15	BOLT EXTRACTOR	15mm
7	AK728.16	BOLT EXTRACTOR	16mm
8	AK728.17	BOLT EXTRACTOR	17mm
9	AK728.19	BOLT EXTRACTOR	19mm
	AK728.SR	STRAIGHT ROD	74mm



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of this equipment.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

CIALLY CLALLY TOOLS Bury St. Edmunds, Suffolk.	O1284 757500 O1284 757500 O	🚱 Web address: www.sealey.co.uk
	📇 01284 703534	E-mail: sales@sealey.co.uk
		AK728 - 2 - 021105



Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- **WARNING! DO NOT** use the sockets if damaged. Maintain the sockets in good condition and replace any that become damaged or worn.
- Ensure all workshop safety rules, regulations and condition are complied with when using the set.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Wear appropriate eye protection.
- ✓ The work area should be clean, well lit and free from unnecessary clutter.
- ✓ Keep children and unauthorised persons away from the work area.

2. INTRODUCTION

2.1. Drop forged Chrome Molybdenum steel sockets. Reverse spiral flutes are designed to bite down to provide maximum gripping power. Set comes complete with 8mm straight rod to knock bolt out after use. Supplied in carry-case.

3. OPERATION

Note: The set is only useful for bolts with a positive thread.

- 3.1. Select an appropriate socket and position it over the bolt to be removed.
- 3.2. Strike the socket with a hammer, thereby forcing it onto the bolt.
- 3.3. Use a manual wrench to loosen the bolt.
- 3.4. Use the rod provided to remove the bolt from the socket.

ltem	Part No	Description	
1	AK728.10	BOLT EXTRACTOR	10mm
2	AK728.11	BOLT EXTRACTOR	11mm
3	AK728.12	BOLT EXTRACTOR	12mm
4	AK728.13	BOLT EXTRACTOR	13mm
5	AK728.14	BOLT EXTRACTOR	14mm
6	AK728.15	BOLT EXTRACTOR	15mm
7	AK728.16	BOLT EXTRACTOR	16mm
8	AK728.17	BOLT EXTRACTOR	17mm
9	AK728.19	BOLT EXTRACTOR	19mm
	AK728.SR	STRAIGHT ROD	74mm



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. **IMPORTANT:** No liability is accepted for incorrect use of this equipment.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

Sole of Distributor	1284 757500	Web address: www.sealey.co.uk
Sole UK Distributor Sealey Group, TOOLS Bury St. Edmunds, Suffolk.	📇 01284 703534	E-mail: sales@sealey.co.uk