SEALEY

THE TOOL COMPANY

Premier Multipurpose Trolley for Diagnostics, 3-Level

OPERATOR INSTRUCTION MANUAL



Model No.

APDT455

Important: Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.

© Jack Sealey Limited

Table of Contents

1.	**Introduction**	**2**
1.1	Intended Use	2
1.2	Description	2
2.	**Safety Symbols**	**3**
3.	**Safety**	**3**
4.	**Specification**	**3**
5.	**Contents**	**4**
6.	**Assembly**	**4**
7.	**Consumables & Accessories**	**6**
8.	**Maintenance**	**6**
9.	**Warranty**	**6**
10.	**Aftersales Support**	**6**
11.	**Parts Information - APDT455**	**7**

1. Introduction

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

1.1 Intended Use

The Premier Multipurpose Trolley (3-Level) is designed for the convenient storage, transport, and organisation of diagnostic equipment, tools, accessories, and related workshop items. It is intended for use in workshops, garages, service centres, and similar professional environments where equipment needs to be moved safely and efficiently between work areas. The trolley should only be used on firm, level surfaces and within its specified load capacity. It is not intended for carrying people, lifting loads, or any purpose other than the storage and transportation of equipment and materials.

1.2 Description

Durable cold-rolled steel construction with a compact, powder-coated finish. Features three shelves, four drawers including one with a combination lock, cable management hole and rear and side hooks. Storage for laptops, diagnostic testers, leads, chargers and workshop equipment. Fitted with two braked swivel front castors and two fixed rear castors for easy mobility.

© Jack Sealey Limited

All content in this manual, including but not limited to text, images, graphics and logos is the property of Jack Sealey Ltd. or its licensors and is protected by copyright, trademark, and other intellectual property laws. You may not reproduce, distribute, modify, or otherwise use any content without prior written consent.

Disclaimer: All errors and omissions excluded. It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See **www.sealey.co.uk** for the latest information.

Country of origin: China.

2. Safety Symbols



Refer to instruction manual



Wear protective gloves

3. Safety

! **WARNING!** Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this storage system.

! **WARNING!** Use storage on level and solid ground, preferably concrete.

- Locate in a suitable work area.
- Keep the work area clean, uncluttered and ensure there is adequate lighting.
- Keep the storage system clean and tidy in accordance with good workshop practice.
- Keep children and unauthorised persons away from the work area.

⃠ **DO NOT** use the storage system for any purpose other than that for which it is designed.

⃠ **DO NOT** use the storage system outdoors.

⃠ **DO NOT** place the storage system in a damp or wet location or an area where there is condensation.

⃠ **DO NOT** clean the storage system with any solvents which may damage the surfaces or the protective coating.

⃠ **DO NOT** move the storage system when there are items placed inside.

⃠ **DO NOT** step on the shelves.

⃠ **DO NOT** overload the storage system.

4. Specification

Model No:	**APDT455**
Overall Size (W x D x H):	750 x 530 x 1005mm

© Jack Sealey Limited

5. Contents




Note: The item numbers shown in the assembly steps correspond to the part numbers listed in the Parts List. For component identification and positioning, refer to both the assembly illustrations and the photograph provided in this manual. Ensure all parts are correctly positioned before fully tightening the fixings.

Note: The M6 × 12 mm Hex Socket Pan Head Screws are supplied pre-assembled with a washer and spring washer.


6. Assembly

Step.1




Install the castors onto the base plate according to the positions shown in the diagram. Secure them with Spring Washer M12 Zinc and Steel Nut M12 Domed Zinc as shown.

Step.2




Locate the left-hand side panel, left-hand outer panel, and two brackets. Attach the left-hand outer panel to the left-hand side panel as shown in the diagram. Secure the outer panel and Wire Support using the supplied fasteners.

Step.3



Locate the right-hand side panel, right-hand outer panel, and two brackets. Attach the right-hand outer panel to the right-hand side panel as shown in the diagram. Secure the components and brackets using the supplied fixings.


Step.4



Attach the left-hand and right-hand side panels to the base assembly completed in Steps 1, 2 and 3 using the supplied fixings.


© Jack Sealey Limited

Step.5



Fit the handle, upper rear cover, tool hanger, lower rear cover, and horizontal support as shown in the diagram. Secure all components using the supplied fasteners.


Step.6



Install the upper front panel as shown in the diagram and secure it using the supplied fasteners.


NOTE: Drawer slides are pre-installed on the upper front panel.

Step.7




Position the top and middle shelves as shown in the diagram and secure them using the supplied fasteners.

Step.8



Install the upper side drawer into the drawer slides as shown in the diagram.

Step.9



Install the front drawers as shown in the diagram. Attach the hook-and-loop retaining strap (not illustrated). Refer to the photograph in the Contents section for guidance.

Note: Drawer slides are pre-installed on the side panels.

© Jack Sealey Limited

7. Consumables & Accessories

A wide range of consumables and accessories are available.

Visit www.sealey.co.uk to explore our extensive range.

8. Maintenance

8.1 To maintain the performance and appearance of this product, please read and follow the care guidelines below:

- Avoid dragging or rubbing the product against rough surfaces, as this may damage the finish, particularly the sheet metal components.
- Regularly inspect all fasteners, fittings, and connections. Tighten any loose parts to ensure safe operation. To help prevent corrosion and extend the product's service life, periodically inspect metal components and treat any signs of rust or corrosion as required.
- Always follow safe operating procedures and do not exceed the product's rated load capacity. Ensure all safety features remain in place and in good working order. Address any potential safety issues promptly.
- Regularly inspect the product for wear or damage. Adjust components as necessary and replace any worn or damaged parts. Avoid contact with corrosive substances or liquids.
- When not in use, store the product in a clean, dry location.

! **DO NOT** store it in hot, damp, or poorly ventilated areas.

9. Warranty

- Guarantee is 10 years from purchase date, proof of which is required for any claim.

Please note that guarantee claims must be made via the place of purchase where you may need to provide proof of purchase. All consumable items are under no warranty period. All warranties exclude general wear and tear and misuse, see our terms of business for more details.

10. Aftersales Support

We are committed to supporting our products throughout their lifetime.

- If your product is outside of the warranty period, we offer an extensive range of spare parts along with expert technical advice to help keep your equipment in working order.
- Our technical team is on hand to assist 8.30am-5.00pm Mon-Fri with fault finding, repairs and general product queries.

  Telephone 01284 757505

  Email: technical@sealey.co.uk

If required, products can also be returned to Sealey or one of our authorised repair agents for inspection, servicing or repair at a reasonable cost.

© Jack Sealey Limited

11. Parts Information - APDT455

Qty	Part Number	Description	Number
2	APDT455-01	Wheel, Swivel Castor, Single bolt w/Brake	**1**
2	APDT455-02	Wheel, Swivel Castor, Single Bolt	**2**
1	APDT455-03	Left Side Panel	**3**
1	APDT455-04	Right Side Panel	**4**
1	APDT455-05	Lower Draw	**5**
2	APDT455-06	Middle Draw	**6**
1	APDT455-07	Upper Draw	**7**
4	APDT455-08	Wire Support	**8**
1	APDT455-09	Left Outer Panel	**9**
1	APDT455-10	Right Outer Panel	**10**
1	APDT455-11	Top Shelf	**11**
1	APDT455-12	Rear Cover Upper	**12**
1	APDT455-13	Tool Hanger	**13**
1	APDT455-14	Handle	**14**
1	APDT455-15	Upper Front Cover	**15**
1	APDT455-16	Middle Shelf	**16**
1	APDT455-17	Horizontal Support	**17**
1	APDT455-18	Rear Cover Lower	**18**
1	APDT455-19	Base	**19**
6	APDT455-20	Ball Bearing Silde 12”	**20**
2	APDT455-21	Ball Bearing Silde 14”	**21**
4	SN12.SD	Steel Nut M12 Domed Zinc	**22**
4	SWM12.S	Spring Washer M12 Zinc	**23**
43	APDT455-24	Hex Socket Pan Head Screw M6 x 12mm	**24**
1	APDT455-25	Cable Cover	**25**
1	APDT455-26	Reverse-Hook-and-Loop Strap	**26**
1	APDT455-27	19mm Open- End Wrench	**27**
1	APDT455-28	Flat Head Hex Wrench M4 x 67 x 67	**28**
1	APDT455-29	4mm Hex Screwdriver Bit	**29**
2	FN6.S	Flange Nut Serrated M6 Zinc	**30**
1	APDT455-31	Combination Lock	**31**

Product Registration

It’s quick and easy to register your warranty online at www.sealey.co.uk. Just log in or create a free MySealey account, then head to the ‘My Products’ section to fill out the short warranty registration form. If your product is advertised with a free extended warranty upon registration, this will activate your extended warranty.

Environment Protection

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Jack Sealey (EU) Ltd t/a Sealey Group Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Sealey Group Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Tel: 01284 757500 ▪ **Email:** sales@sealey.co.uk ▪ **Web:** www.sealey.co.uk

© Jack Sealey Limited