

# LUKAS REAR PADDOCK STAND FOR BSA RANGE 2023 ONWARDS

MODEL NO: **BSAPS2**

Manufactured by



Thank you for purchasing a LUKAS/BSA Approved product. This product is designed and manufactured to a high standard and is specifically compatible to BSA Goldstar, Scrambler, Bantam Motorcycles.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to  
instruction  
manual



Wear protective  
gloves



Wear protective  
footwear

## 1. SAFETY

- ☐ **WARNING!** Before use, ensure that there is nothing attached to the rear end of the motorcycle, that will interfere with mounting or dismounting of the stand.
- ☒ **DO NOT** mount the stand on tarmac/adam, as the surface may be unstable.
- ☒ **DO NOT** start the motorcycle when mounted on the stand.
- ☒ **DO NOT** sit on the motorcycle when mounted on the stand.
- ☒ **DO NOT** use the stand for a purpose it is not designed to perform.
- ☒ **DO NOT** use the stand when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ☒ **DO NOT** make any modifications to the stand.
- ☒ Although the stand can be operated by one person, we advise seeking the assistance of a second person when mounting / dismounting the motorcycle from the stand.
- ☒ Using a front wheel chock or a block under the side stand will assist to bring the bike almost to vertical and support the bike while installing the paddock stand.
- ☒ Maintain the stand in a good clean condition for the best and safest performance.
- ☒ Locate the stand and motorcycle in a suitable area. Keep area clean, tidy and free from unrelated materials and ensure that there is adequate lighting. Also ensure that the floor/ground is level and strong enough (preferably concrete) to take the weight of the stand and the motorcycle.
- ☒ Maintain correct balance and footing whilst positioning the motorcycle on the stand, **DO NOT** over reach.
- ☒ Ensure that the floor is not slippery, wear non-slip footwear.
- ☒ Keep children and unauthorised persons away from the work area.
- ☒ Before loading or removing a motorcycle to/from the stand, ensure that there are no obstructions or persons around the motorcycle.
- ☒ Always support bike to prevent falling.
- ☒ When not in use, store in a safe, dry, childproof location.
- ☐ **WARNING:** The warnings, cautions and instructions in this manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.



## 2. INTRODUCTION

Specifically designed to fit the (2023 onwards) BSA Goldstar, Scrambler and Bantam. Lifts and stabilizes the BSA Range of bikes quickly and easily. Fitted with rubber supports mounted directly below the swingarm, so no adjustment required prior to use. Model No. BSAPS2. Delivered in knock-down form to reduce freight costs, some self-assembly required.



### 3. ASSEMBLY

- 3.1. Assemble as per attached Parts Information (and fig.2 below).
- 3.2. Ensure all parts are present and in good order. **DO NOT** use parts other than those supplied.
- 3.3. Ensure all fixings are correctly tightened and that frame members are securely fitted as per fig.1.



### 4. OPERATION

- 4.1. Ensure all fixings are correctly tightened and that frame members are securely fitted before each use.
- 4.2. Using a front wheel chock or a block under the side stand will assist to bring the bike almost to vertical and support the bike while installing the paddock stand.
- 4.3. Place the left side of the swingarm is sitting in the U shaped support bracket of the paddock stand. Gently push down on the rear handle of the BSAPS2 and let the right side of the swingarm gently rest on the L support bracket.

### 5. MAINTENANCE

- 5.1. Clean with soft dry or lightly dampened cloth.
  - \* **DO NOT** use solvents or chemical cleaners.
- 5.2. When the stand is not in use, store in dry, clean environment.
- 5.3. Keep the stand clean and wipe off any oil or grease. Lubricate all moving parts with oil e.g. roller wheels.
- 5.4. Before each use check all parts. If any part of the stand is damaged or defective, remove the stand from service and take the necessary action to remedy the problem.
  - \* **DO NOT** use the stand if it is believed to have been subjected to abnormal load or shock. Inspect and take appropriate action.



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

**Jack Sealey Ltd t/a Sealey Group**, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK  
**Jack Sealey (EU) Ltd t/a Sealey Group**, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland  
**Tel:** 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk