



# INSTRUCTIONS FOR: PLATFORM TRUCKS

## Models: **CST 991, CST992, CST993**

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**

### 1. SAFETY INSTRUCTIONS

- 3 Always load evenly with the centre of gravity of the load as near the centre of the truck as possible.
- 3 Obtain additional support for large or wide loads to prevent tipping.
- 7 Do not overload the truck - see Specifications.
- 7 Do not leave unattended, especially when loaded, unless the wheels are chocked or the truck is otherwise secured.
- 7 Do not use truck on uneven ground and do not run over curbs or steps - use a ramp.
- 7 Do not allow others to ride on the truck.
- 7 Do not use the truck if any part is significantly damaged - pay particular attention to the wheels.

### 2. SPECIFICATIONS

	CST991	CST992	CST993
Max. Load	150kg	300kg	250kg
Wheel Diameter	100mm	125mm	125mm
Deck Length/Width/Height	738/479/140mm	916/616/209mm	949/496/226mm
Overall Height	815mm	863mm	961mm



### 3. ASSEMBLY

Numbers/letters in brackets refer to those on the relevant parts diagram.

#### 3.1 CST991 & CST992

- 3.1.1 Remove the bolts and washers (4) from the underside corners of the deck and use then to attach the wheels (2, 3).

**Note!** Two wheels are swivel castors (2), these should be fitted at the handle end of the deck.

#### 3.2 CST993

- 3.2.1 Remove the nuts (8) and washers (7) from the underside corners of the deck and use then to attach the wheels (3, 6).

**Note!** Two wheels are swivel castors (3), these should be fitted at the handle end of the deck.

- 3.2.2. Remove the two screws (5) from the ends of the handle frame (1).
- 3.2.3. Locate the ends of the handle frame in the sockets in the deck frame and retain with the screws.

### 4. ADJUSTMENTS

#### 4.1 CST991 & CST992

- 4.1.1 To lift or to fold down the handle, press the handle locating rod (A) fully down. Release the rod when the handle is in the required position.

**Note!** Only use truck with handle **fully raised**.

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.