Dellonda Chester Rattan Wicker Oval Outdoor Dining Table with Tempered Glass Top & Parasol Hole



Model: DG317

Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.

© Dellonda.co.uk

Table of Contents

1.	**Introduction**	**2**
1.1	Intended Use	2
1.2	About The Product	2
2.	**Safety**	**3**
3.	**Specification**	**3**
4.	**Replacement Parts**	**3**
5.	**Contents**	**3**
6.	**Assembly**	**4**
6.1	Table Base Assembly	4
6.2	Glass Top And Parasol Insert	5
7.	**Maintenance**	**5**
8.	**Warranty**	**5**
9.	**Aftersales Support**	**5**
10.	**End Of Life**	**5**

1. Introduction

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

1.1 Intended Use

Dining table designed for domestic use and suitable for year-round outdoor use.

1.2 About The Product

This modern rattan dining table will work in any outdoor space from large gardens to patios and balconies. The premium quality material has been UV Treated, is fade resistant and can be used outside all year round. Can be used as a dining table, side table, snack table or balcony table. Features an easy-to-clean tabletop that is suitable for consistent outdoor use.

© Jack Sealey Limited trading as Dellonda

All content in this manual, including but not limited to text, images, graphics and logos is the property of Jack Sealey Ltd/Dellonda or its licensors and is protected by copyright, trademark, and other intellectual property laws. You may not reproduce, distribute, modify, or otherwise use any content without prior written consent.

Disclaimer: All errors and omissions excluded. It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See **www.dellonda.co.uk** for the latest information.

Country of origin: China.

2. Safety

- Always read these instructions fully before assembling and using your furniture.
- Take care when handling the table. The glass top is only secured to the table top and base with suckers.

! **WARNING!** Keep all flame and heat sources away from this furniture.

✕ **DO NOT** place hot objects such as pans or dishes directly onto the glass surface. Always use mats or trivets.

✕ **DO NOT** use bleach, alkaline or harsh detergents for cleaning. Soap and warm water are recommended.

✕ **DO NOT** use a high-pressure washer to clean this product.

- This product has a reasonable level of protection against UV degradation, however as with any material it will begin to fade and degrade after long periods of exposure to the sun.

3. Specification













Model	**DG317**
Table Dimensions (W x D x H)	180 x 120 x 74 cm
Net Weight	34kg
Material	Polyurethane Rattan / Aluminium Frame / Tempered Glass Top
Parasol Hole	Ø42mm

4. Replacement Parts

- Replacement parts are available direct from Dellonda. See Section 9: Aftersales Support for details.

Part No.	Description
DG11302	Table Top
DG11303	Table Base End Panel
DG11304	Table Base Side Panel
DG11305	Glass Top
DG11306	Fixing Kit

5. Contents

Item	Description	Reference	Qty
1	Table Top		1
2	Table Base End Panel		2
3	Table Base Side Panel		2
4	Glass Top		1
5	Parasol Insert		1
6	Hex Bolt (M6 x 30mm)		8
7	Hex Bolt (M6 x 20mm)		6
8	Nut (M6)		8
9	Steel Washer (Ø6.5mm)		22
10	Plastic Washer (Ø6.5mm)		8
11	Plastic Bolt Cap (M6)		14
12	Wrench		1
13	Hex Key		1

6. Assembly

6.1 Table Base Assembly

Note: Assembly will require the aid of another person.

6.1.1 Prepare a clean, dry working area.


6.1.2 Place cardboard or another suitable covering to protect the table top.

✕ **DO NOT** fully tighten the fixings until fully assembled. Only fit the plastic bolt head caps (**11**) after all fixings have been fully tightened.

6.1.3 Lay the table top (**1**) face down.

6.1.4 Align one of the end panels (**2**) with the fixing points on the table base **(fig.1.1)** making sure that the fixing brackets are facing inwards.

fig.1




6.1.5 Attach the end panel using 2 x M6x20mm bolts (**7**), and 2 x steel washers (**9**) **(fig.2)**.

6.1.6 Attach the other end panel in the same manner.

6.1.7 Align one of the side panels (3), with the fixing brackets facing inwards, to the fixing point on the table top **(fig.1.3)**.

6.1.8 Attach the side panel onto the table top using 1 x M6x20mm bolt (**7**) and 1 x steel washer (**9**) **(fig.2)**.


fig.2



6.1.9 Attach the side panel to both of the end panels by aligning the fixing brackets. There are two sets of brackets on each inside corner **(fig.1.2)**.

6.1.10 Use 1 x M6x30mm bolt (**6**), 2 x steel washers (**9**), 1 x plastic washer (**10**) and 1 x nut (**8**) for each set of brackets **(fig.3)**.

fig.3



Note: The brackets have elongated holes to allow adjustment where necessary.

6.1.11 Align the remaining side panel and repeat the process of attaching it to the table top first and then the corner brackets.

6.1.12 Once satisfied with the alignment of the components, the fixings can be fully tightened.

6.1.13 The plastic bolt head caps (**11**) can now be fitted by pushing them onto the end of the bolts.

© Dellonda.co.uk

6.2 Glass Top And Parasol Insert

Note: This stage requires the help of another person.

6.2.1 Lift the table and turn it over onto its legs.

6.2.2 Lift the glass table top (**4**) and carefully position it on top of the table so that the edge is evenly aligned with the table top and the hole in the glass is centred with the table top hole **(fig.4)**

6.2.3 Fit the parasol insert (**5**) through the glass and table top **(fig.4)**.

fig.4



6.2.4 Secure it with the locking collar.

✕ **DO NOT** over-tighten

6.2.5 The parasol insert has a cover which must be removed when inserting a parasol through it.

7. Maintenance

7.2.1 Clean with mild soap and water.

7.2.2 Carefully lift the glass off the table to enable full access for a more thorough clean. Allow to dry and refit the glass.

8. Warranty

8.1 Our Warranty is that on delivery and for the relevant Warranty Periods (set out below) the Goods shall be free from material defects in design, material and workmanship.

- If you notify us during the relevant Warranty Periods within a reasonable time of discovery that some or all of the Goods do not comply with Our Warranties, we shall, at our option, repair or replace the individual faulty component of the Goods or refund the price of the faulty Goods in full. In order to be validated, a proof of purchase (invoice or receipt) must be supplied to us with any returned item where it is claimed that some or all of the Goods do not comply with Our Warranty.
- All Dellonda products are covered by a minimum 1-year warranty (“the Warranty”) (unless otherwise specified). This warranty covers against manufacturing defects and excludes general wear and tear and any serviceable/ consumable items.

9. Aftersales Support

We are committed to supporting our products throughout their lifetime.

- If your product is outside of the warranty period, we offer an extensive range of spare parts along with expert technical advice to help keep your item in working order.
- Our technical team is on hand to assist 08:30 - 17:00 Mon-Fri with fault finding, repairs and general product queries.

  Telephone: 01284 757575

  Email: support@dellonda.co.uk

If required, products can be returned to us for inspection, servicing or a repair at a reasonable cost.

10. End Of Life

At the end of its service life, this product must be disposed of in an environmentally responsible manner. Components such as metal parts should be recycled wherever possible.

✕ **DO NOT** discard the appliance with general household or construction waste. Please follow all local environmental regulations to ensure safe and sustainable disposal.

Environment Protection

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Jack Sealey (EU) Ltd t/a Dellonda Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Jack Sealey Ltd t/a Dellonda Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Tel: 01284 757575 ▪ **Email:** support@dellonda.co.uk ▪ **Web:** www.dellonda.co.uk

© Dellonda.co.uk