# 24" Home/Work High Velocity Floor Fan 230V




## Model: DH498

### Important Information

Please read these instructions carefully. Note the safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.

© Baridi.com

## Table of Contents


| | | |
|---|---|---|
| **1.** | **Introduction** | **2** |
| 1.1 | Intended Use | 2 |
| 1.2 | Description | 2 |
| **2.** | **Safety Symbols** | **3** |
| **3.** | **Safety** | **3** |
| **4.** | **Electrical Safety** | **3** |
| **5.** | **Specification** | **4** |
| **6.** | **Features** | **4** |
| **7.** | **Operation** | **4** |
| **8.** | **Consumables & Accessories** | **4** |
| **9.** | **Maintenance & Storage** | **5** |
| **10.** | **Breakdown Or Accident** | **5** |
| **11.** | **Cleaning** | **5** |
| **12.** | **Testing** | **5** |
| **13.** | **Transport, Handling & Storage** | **5** |
| **14.** | **Warranty** | **5** |
| **15.** | **Aftersales Support** | **5** |
| **16.** | **End Of Life** | **6** |
| **17.** | **Parts Information** | **6** |
| 17.1 | Parts Diagram | 6 |
| 17.2 | Parts List | 6 |
| **18.** | **Troubleshooting** | **7** |
| **19.** | **Product Information Sheet** | **7** |


# 1. Introduction

Thank you for purchasing a Baridi product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

## 1.1 Intended Use

This 24-inch high velocity floor fan is intended for providing high-volume air circulation and ventilation in residential, commercial, and light industrial environments. It is suitable for cooling occupied spaces, improving airflow, and assisting with drying applications in accordance with the manufacturer's instructions.

## 1.2 Description

High velocity fan delivering up to 155m³/min (5484cfm) airflow for rapid air movement in home, work, gym, dentist, pub and more environments. Two-speed power selection allows airflow to be adjusted to suit a wide range of applications. Cradle stand enables accurate positioning of airflow exactly where it is needed. Carefully balanced fully guarded blades 24 inch(610mm) provide smooth performance with reduced operating noise. Supplied with fitted 3-pin plug and 3 metre power cable for quick and easy setup. Low energy rating and ERP Compliant.


**© Jack Sealey Limited trading as Baridi**

All content in this manual, including but not limited to text, images, graphics and logos is the property of Jack Sealey Ltd/Baridi or its licensors and is protected by copyright, trademark, and other intellectual property laws. You may not reproduce, distribute, modify, or otherwise use any content without prior written consent.


**Disclaimer:** All errors and omissions excluded. It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See **www.baridi.com** for the latest information.

**Country of origin:** China.

## 2. Safety Symbols



Refer to instruction manual



Indoor use only



**Warning!** Electric shock hazard



**DO NOT** operate unless guards are fitted



**DO NOT** operate the fan where there are explosive or flammable gases, fumes or other hazardous substances



Wear eye protection

## 3. Safety

- Read and understand the user manual before operating the fan.
- Never leave the unit running unattended.
- Ensure front and rear vents remain free from obstructions during operation.
- Conduct a risk assessment of the required work environment and application.

⃠ **DO NOT** use in explosive atmospheres or other hazardous substances.

⃠ **DO NOT** modify the equipment or use it for purposes other than those intended.

⃠ **DO NOT** position the fan against walls or structures that restrict airflow.

⃠ **DO NOT** use the fan if there are signs of damage that could create a hazard.

### 3.1 Personal Precautions

- Ensure hands are dry when connecting to the mains supply, or disconnecting the fan.
- Wear suitable PPE, including eye protection, before operating.

⃠ **DO NOT** pull the plug from the socket by the cable.

### 3.2 General Safety

- Ensure the cable is fully unwound before operation.
- Always set the speed selector to ‘0’ (Off) before switching on the appliance.
- Switch off and disconnect the fan from the mains supply during prolonged periods of non-use.
- Ensure the mains cable does not create a trip hazard.
- Avoid routing cables across walkways, paths, or doorways.
- Secure the cable once positioned and keep it away from sharp edges, water, and chemicals.
- Children shall NOT play with the appliance.
- Cleaning and user maintenance on the appliance shall not be made by children without supervision.

## 4. Electrical Safety

! **WARNING!** It is the user’s responsibility to check the following:

- Check all electrical equipment and appliances to ensure that they are safe before using.
- Inspect the fan, mains cable, and plug for damage before each use.
- Use an RCD (Residual Current Device) where recommended.
- Verify that the plug fuse and circuit protection are correctly rated for the equipment.
- Inspect power supply leads, plugs and all electrical connections for wear and damage.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

⃠ **DO NOT** use worn or damaged cables, plugs or connectors.

- Ensure that any faulty item is repaired or replaced immediately by a Baridi qualified technician.
- If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- Baridi recommend that an RCD (Residual Current Device) is used with all electrical products.

! **IMPORTANT!** Ensure that the voltage rating on the appliance suits the power supply.

## 5. Specification

| | |
|---|---|
| **Model** | DH498 |
| **Current:** | 0.5A |
| **Fan Diameter:** | Ø610mm(24") |
| **Fan Power Input (P):** | 116.32W |
| **Fuse Rating:** | 3A |
| **Fan Sound Power Level (Lwa)** | 84dB(A) |
| **IP Rating** | IP44 |
| **Maximum Airflow:** | 155.3m³/min(5484cfm) |
| **Maximum Air Velocity (C):** | 3.66m/sec |
| **Nett Weight:** | 14.50kg |
| **Plug Type:** | 3-Pin |
| **Power Supply Cable Length:** | 3m |
| **Power:** | 116.32W |
| **Speed Range:** | 1350-1450rpm |
| **Speeds:** | 2 |
| **Supply:** | 230V~ 50Hz |
| **Service Value (SV):** | 1.34(m³/min)/W |

## 6. Features

**Fig.1**




| | |
|---|---|
| **1** | Control Panel On Rear |
| **2** | Power Cable |
| **3** | Safety Grill |
| **4** | Motor and Fan Blade Assembly |
| **5** | Wheels |


**Diagram Is For Reference Only**

## 7. Operation

- Remove all packaging and transit restraints before use.
- Ensure the fan is positioned on a stable, level surface with unrestricted airflow to the front and rear.
- Check that the fan, power cable and plug are free from damage before connecting to the power supply.
- Ensure the speed selector switch is in the OFF (0) position before connecting to the mains supply.
- Connect the fan to a suitable power supply.

**Control panel**

**Diagram For Reference Only** **Fig.2**




| | |
|---|---|
| **0** | Off no air flow |
| **1** | Low Speed setting |
| **2** | High Speed Setting |

There is a dedicated earth point clearly identified on the control panel for class 1 earth continuity testing.

## 8. Consumables & Accessories

- A wide range of consumables and accessories are available.

**Visit www.sealey.co.uk to explore our extensive range.**

© Baridi.com

## 9. Maintenance & Storage

- To maximise fan performance, ensure that the front and rear ventilation openings remain free from obstructions at all times.
- Before each use, visually inspect the unit, power cable, and plug for signs of damage.
- Store the unit in a clean, dry location when not in use.

## 10. Breakdown Or Accident

- In the event of a breakdown, abnormal operation, or accident, switch the fan off immediately and disconnect it from the mains power supply. **DO NOT** attempt to operate or repair the unit until it has been inspected by a competent person. If damage to the power cord, plug, guard, or fan assembly is observed, remove the fan from service and clearly mark it as defective.

## 11. Cleaning

- Unplug the fan before cleaning.
- Remove dust with a brush, vacuum, or soft cloth.
- Wipe with a damp cloth and dry thoroughly.

⊘ **DO NOT** immerse in water or allow water to enter the motor.

⊘ **DO NOT** use abrasive cleaning products.

## 12. Testing

! This is a Class I appliance and must be earthed.
The earth test point is located on the control panel and is identified by the earth symbol. Electrical safety testing should be carried out in accordance with your site's maintenance procedures and applicable regulations.

⊘ **DO NOT** attempt to repair damaged Home /work industrial fan components. Replace damaged parts before use.

## 13. Transport, Handling & Storage

- When transporting or handling the fan, ensure it remains upright and is securely fastened to prevent movement, impact, or damage during transit. Use appropriate lifting techniques when carrying the unit and never lift it by the power cord, guard, or blades. Store and transport the fan in a clean, dry location, protected from moisture, excessive dust, and extreme temperatures. Before use, inspect the fan carefully for any signs of damage that may have occurred during transportation or handling.

## 14. Warranty

- Our Warranty is that on delivery and for the relevant Warranty Periods (set out below) the Goods shall be free from material defects in design, material and workmanship.
- If you notify us during the relevant Warranty Periods within a reasonable time of discovery that some or all of the Goods do not comply with Our Warranties, we shall, at our option, repair or replace the individual faulty component of the Goods or refund the price of the faulty Goods in full. In order to be validated, a proof of purchase (invoice or receipt) must be supplied to us with any returned item where it is claimed that some or all of the Goods do not comply with Our Warranty.
- All Baridi products are covered by a minimum 1-year warranty ("the Warranty") (unless otherwise specified). This warranty covers against manufacturing defects and excludes general wear and tear and any serviceable/ consumable items.

## 15. Aftersales Support

**We are committed to supporting our products throughout their lifetime.**

- If your product is outside of the warranty period, we offer an extensive range of spare parts along with expert technical advice to help keep your item in working order.
- Our technical team is on hand to assist 09:00 - 17:00 Mon-Fri with fault finding, repairs and general product queries.

  Telephone: 01284 757575

  Email: support@baridi.com

If required, products can be returned to us for inspection, servicing or a repair at a reasonable cost.


## 16. End Of Life

- At the end of its service life, this product must be disposed of in an environmentally responsible manner. Components such as metal parts should be recycled wherever possible.

✕ **DO NOT** discard the appliance with general household or construction waste. Please follow all local environmental regulations to ensure safe and sustainable disposal.

## 17. Parts Information

### 17.1 Parts Diagram




### 17.2 Parts List

| Item | Part No. | Description |
|---|---|---|
| 1 | DH11809 | Front Guard |
| 2 | DH11810 | Fan Blade 24" |
| 3 | DH11811 | Drum Handle |
| 4 | DH11812 | Drum |
| 5 | DH11813 | Rear Guard |
| 6 | DH11814 | Motor, External (220-240V 50Hz) |
| 7 | DH11815 | Switch |

| Item | Part No. | Description |
|---|---|---|
| 8 | DH11816 | Switch Box |
| 9 | DH11817 | Speed Switch Knob |
| 10 | DH11818 | Capacitor for Compressor |
| 11 | MC3CX0.75 | Mains Cable Blk, 3 Core, 0.75mm² (Per Metre) |
| 12 | DH11819 | Adjustable Knob |
| 13 | DH11820 | Base |
| 14 | DH11821 | Fixed Wheel |

## 18. Troubleshooting

| Fault | Possible Cause | Corrective Action |
|---|---|---|
| Fan not operating. | No power supply. | Check that the unit is connected to a suitable power supply and switched on. |
| | Damaged power cable or plug. | Remove the unit from service and have it inspected by a competent person. |
| Reduced airflow. | Ventilation openings blocked. | Remove any obstructions from the front and rear ventilation openings. |
| Excessive noise or vibration. | Foreign object or damage to fan assembly. | Switch off the unit and inspect for damage. Remove from service if a fault is found. |

## 19. Product Information Sheet

**Product Information Sheet. Fans ≤ 125 kW.**

| | |
|---|---|
| SUPPLIER_NAME_OR_TRADEMARK | Sealey EU Ltd. |
| DELEGATED_ACT | 206/2012/EU |
| MODEL_IDENTIFIER | DH498 |
| Baridi 24" Home/Work High Velocity Floor Fan 230V | |
| ADDRESS | Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland |
| PHONE_NUMBER | 01284 757 500 |
| EMAIL_ADDRESS | TechnicalCompliance@sealey.co.uk |

| Parameter | Verification tolerances |
|---|---|
| Maximum fan flow rate. m3/min | 155.3 |
| Fan power input. W | 116.3 |
| Service value. (m3 /min)/W. | 1.3 |
| Standby power consumption. Watt. | 0.0 |
| Fan sound power level. dB(A). | 84 |
| Maximum air velocity. meters/sec. | 3.7 |
| Measurement standard for service value. | IEC 60879 |

| | |
|---|---|
| Suppliers website | https://www.sealey.co.uk/ |

**Weee Regulations**

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.

**Product Registration**

It's quick and easy to register your warranty online at www.sealey.co.uk. Just log in or create a free MySealey account, then head to the 'My Products' section to fill out the short warranty registration form. If your product is advertised with a free extended warranty upon registration, this will activate your extended warranty.

**Environment Protection**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Jack Sealey (EU) Ltd t/a Baridi** Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
**Jack Sealey Ltd t/a Baridi** Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
**Tel:** 01284 757575 ▪ **Email:** support@baridi.com ▪ **Web:** www.baridi.com

© Baridi.com