

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

! IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY, AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- ✓ Decide on a safe height above the table and ensure it is clamped securely.
- ✓ The lamp is designed to be used beneath a parasol, protected from the rain.
- ✓ Store the lamp inside when not in use.
- x **DO NOT** attempt to replace the LED's.
- x **DO NOT** use the lamp for any purpose other than for which it is designed.
- x **DO NOT** use the auxilliary socket. (Not connected on this model)

2. INTRODUCTION

Lightweight composite structure has been designed to easily fit most parasol centre support beams, ranging from Ø30mm to Ø45mm. Spring loaded ribbed rubber grips strengthen the grip around the centre beam. Quick release button opens lamp for easy and simple fitting. 16 LED lights mounted at an angle to give wide spread of light for evenings outside. Powered by 3 x AA batteries (not included)

3. SPECIFICATION

Description:.....Specification
 LED's:.....16
 Type of batteries:.....3 x "AA" (not supplied)
 Fitting pole size:.....Ø30-Ø45mm
 Operating time:.....6-8 hours
 Dimensions:.....Ø200mm x 60mm



Release button



Jaws

On/off button

4. OPERATION

- 4.1 Remove battery compartment lid situated on opposite face to lights and observe polarity, as shown in moulding. Insert 3 "AA" batteries (not supplied) into compartment and replace lid.
- 4.2 Press the release button to open the segments.
- 4.3 "Wrap" around the pole centrally for best grip, and snap closed.
- 4.4 Press on/off button to switch lights on/off. Switch off after use.



Environmental Protection. Recycle unwanted packaging materials or dispose of in a manner which is compatible with the environment. When the product is no longer required, dispose of in an environmentally protective way. Open battery compartment as described in Section 4.1 and dispose of batteries according to local authority guidelines.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
 Kempson Way, Suffolk Business Park,
 Bury St. Edmunds, Suffolk,
 IP32 7AR

01284 757500

www.sealey.co.uk

01284 703534

sales@sealey.co.uk