

3W SMD LED RECHARGEABLE 3 IN 1 SPOTLIGHT

MODEL NO: LED140

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



instructions

1. SAFETY

1.1. GENERAL

- \checkmark Ensure the lamp is fully charged before initial use.
- **x DO NOT** turn the lamp on when it is being charged.
- DO NOT shine directly into your, other person's or an animal's eyes.
- DO NOT allow children to use the lamp.
- **× DO NOT** handle or move the lamp whilst it is being charged.
- * DO NOT use the lamp if you suspect that the battery, the lamp casing or the cable is damaged. Consult your Sealey Stockist.
- * DO NOT leave battery in a discharged state, recharge battery immediately. Before storage, fully recharge the battery, subsequently recharge the battery at least once every six months of non-use.

1.2. BATTERY SAFETY

- WARNING! To reduce the risk of burns or fire:
- DO NOT Attempt to open, dismantle, modify or service the battery pack.
- * **DO NOT** Crush, puncture, short external contacts or dispose of in fire or water.
- **DO NOT** Expose to temperatures above 40°C or below -10°C.
- **× DO NOT** Expose to direct sunlight for long periods of time.
- **× DO NOT** Expose to moisture.
- WARNING! Do not place the lamp face down while in use.
- Replace only with the battery pack designated for this product.
- ✓ Recycle or dispose of used battery as stipulated by local regulation.
- If the electrolyte in the cells gets on your skin, wash thoroughly with soap and water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

2. INTRODUCTION

Rechargeable 3W SMD LED 105 Lumen Spotlight and 60 Lumen Lantern. Lantern produces 360 degrees lighting with two settings. SMD LED Desk Lamp producing 180 lumens. Desk Lamp has two settings with adjustable lighting angle. Slide switch and quick release button to change the light function. Charging USB cable included. 1500mAh li-ion battery.

3. SPECIFICATION

Model No: LED140
Battery:
Charging Time: 4hours
IP Rating: IP20
LED Qty:
LED Type:SMD
Power:
Lumen Output:
Spotlight: 105
Lantern: High- 60, Low- 30
Desk Lamp: High- 180, Low- 100
Operating Time:
Spotlight: 8 Hrs
Lantern: High- 6 Hrs, Low- 8 Hrs
Desk Lamp: High- 6 Hrs, Low- 8 Hrs



The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time.

We will provide warranty against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish.

Under these circumstances we will not replace the battery regardless of whether it is less than one year old.

NOTE: The lithium battery does not suffer from memory effect and once fully charged may be stored for up to six months without another charge.

4. OPERATION

IMPORTANT: Only use the cable supplied with the product.

4.1. CHARGING

- 4.1.1. Insert the Micro USB plug into the power inlet on the rear of the lamp (fig.2).
- 4.1.2. Plug the other end of the USB cable into a 5V USB outlet.
- WARNING! DO NOT turn lamp on whilst charging.
- 4.1.3. The charge indicator (fig.2) will blink during charging. When fully charged the indicator will be on continuously.
- 4.2. USE OF SPOTLIGHT/LANTERN (Handle arrangement closed)
- 4.2.1. Direct the lens away from your eyes, other people and animals before switching on.
- 4.2.2. Slide the ON/OFF switch (fig.1) up one 'click' for LOW lantern mode, again for HIGH lantern mode. Once more for spotlight. Slide the switch back to its starting position to turn the whole unit off.
- 4.3. USE OF DESK LAMP (Handle arrangement open)
- 4.3.1. Open handle by pressing the head release button on lens housing front face (fig.2).
- 4.3.2. Adjust orientation of lamp and arm to suit required illumination. Lamp can be rotated if required (fig.3, fig.4).
- 4.3.3. Slide the ON/OFF switch (fig.1) up once for LOW lamp mode, again for HIGH lamp mode. Sliding the switch one more time turns off the lamp and turns on the torch. Slide the switch back to its starting position to turn the whole unit off.

4.4. USE OF CHARGING OUTPUT

4.4.1. Connect the USB cable of device to be charged to the charging output port in the unit's body (fig.2).





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 01284 703534 R sales@sealey.co.uk rww.sealey.co.uk