

10W SMD LED 3-IN-1 FOLDING FLOODLIGHT MODEL NO: **LED15WFL**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



1. SAFETY

1.1. ELECTRICAL SAFETY

USE ONLY THE SUPPLIED USB CABLE FOR CONNECTING FLOODLIGHT TO THE POWER SUPPLY.

WARNING! It is the user's responsibility to read, understand and comply with the following electrical instructions: You must ensure the risk of electric shock is minimised by the installation of appropriate safety devices. An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products, particularly portable equipment which is plugged into an electrical supply not protected by an RCCB. You must also read and understand the following instructions concerning electrical safety.

1.1.1. **The Electricity At Work Act 1989** requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT).

The Health & Safety at Work Act 1974 makes owners of electrical appliances responsible for the safe condition of the appliance and the safety of the appliance operator. If in any doubt about electrical safety, contact a qualified electrician.

Inspect the USB cable and connector for wear and damage to ensure items are safe before connecting to a power supply. If worn or damaged **DO NOT** use.

1.2. BATTERY SAFETY

- WARNING! To reduce the risk of burns or fire:
- * DO NOT attempt to open, disassemble, modify or service the battery.
- DO NOT expose to temperatures above 60°C (140°F).
- * DO NOT crush, puncture, short external contacts or dispose of in fire or water.

1.3. GENERAL SAFETY

- Ensure the floodlight is correctly charged before initial use.
- **× DO NOT** cover or block the lens during use.
- **DO NOT** turn the floodlight on when it is being re-charged.
- * DO NOT shine directly into your, other person's or animal's eyes.
- **× DO NOT** allow children to use the floodlight.
- **DO NOT** handle or move the floodlight whilst it is being charged.
- * DO NOT use the floodlight if you suspect that the battery or the spotlight casing is damaged.
- **× DO NOT** immerse the floodlight in water.
- Ensure the floodlight is unplugged and allowed to cool before attempting any cleaning or storage.
- ✓ When not in use, store the floodlight in a safe, dry, childproof location.

2. INTRODUCTION

3-in-1 Design makes this light perfect for almost any situation and workplace. Folding floodlight can either be placed into the stand folded to illuminate both sides of a room or folded up to create one long floodlight. Floodlight supplied with a strong base to keep the light upright and in position. Fold out magnets are situated at either end to be used as an under-bonnet light. The light also features hooks at either end and one centrally so you can hang it almost anywhere. Very bright 1000 lumen light with three different light settings. Rechargeable 3.7V Li-ion 4000mAh battery supplied with USB charging cable.

3. SPECIFICATION

Model No	LED15WFL
Battery	
Charging time	5-6hrs
Colour Temperature	6000K
IP rating	IP20
Lumen Output	
LED type	
Operating Time	2 hrs both sides, 4 hrs one side
Power	

4. OPERATION

The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time. We will provide warranty against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery regardless of whether it is less than one year old.

- **WARNING!** Ensure that you read, and fully understand the safety instructions before use.
- **NOTE:** Before initial use, fully charge the unit.

4.1. BATTERY CHARGING

- 4.1.1. Ensure the floodlight is turned off before charging (Fig.1).
- 4.1.2. Battery charge level is indicated by the LED display (Fig.2).Red charging light will indicate charging and goes to green when fully charged.
- 4.1.3. When full charge has been reached, unplug the charger cable from the power supply.


4.2. USING THE FLOODLIGHT

- 4.2.1. Turn floodlight on and off using the mode switch (Fig.1) on the main body.
- 4.2.2. The floodlight has three working modes selected by use of the Mode Selector switch (Fig.1).
- 4.2.3. Operating modes are: lights illuminated, followed by either front or back light lit independently.
- 4.2.4. Adjust the position of the light using the ratchet effect built into the joints of the frame.
- 4.2.5. The light assembly has magnetic feet and a sprung hook see Fig's 3 to Fig.6 for usage.

5. MAINTENANCE

- **WARNING!** Ensure that you read, understand and apply the safety instructions relating to the battery before charging it.
- **5.1.** Ensure the floodlight is turned 'Off' before attempting to charge the battery.
- 5.2. Wipe down dirty surfaces with damp cloth. DO NOT use abrasive or caustic cleaning materials.
- 5.3. Dispose of broken unit in accordance with local authority battery regulations. DO NOT dispose of with regular refuse.
- 5.4. STORAGE
- 5.4.1. Store the charger in a safe, dry location.
 - NOTES:
 - DO NOT fully discharge the batteries before recharging.

DO NOT leave batteries in a discharged state, recharge batteries immediately. If the floodlight is not in use, recharge the batteries every three months.



Full Upright position. Top or bottom or both can be illuminated.



Hook for under car bonnet use or hanging from a draw etc.

LED15WFL Issue:1 19/01/23



Corner light for inside tool box or overhead cupboard



Magnetic feet which pull out from the internal sides of body. So can be mounted on any magnetic surface.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 Ø komplexed and the sealey.co.uk Ø komplexed by the sealey.co.uk Ø komplexed by the sealey.co.uk Ø

Original Language Version