

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



**IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**

## 1. SAFETY

### 1.1. GENERAL

- ✓ Ensure the lamp is correctly charged before initial use.
- ✗ **DO NOT** turn the lamp on when it is being re-charged.
- ✗ **DO NOT** shine directly into your, other person's or animal's eyes.
- ✗ **DO NOT** allow children to use the lamp.
- ✗ **DO NOT** handle or move the lamp whilst it is being charged.
- ✗ **DO NOT** use the lamp if you suspect that the battery or the lamp casing is damaged.
- ✗ **DO NOT** leave battery in a discharged state, recharge battery immediately. If the lamp is not in use, recharge the battery every month.

### 1.3. ELECTRICAL SAFETY FOR USE OF CHARGER.

#### USE ONLY THE SUPPLIED CHARGER PLUG FOR CONNECTING TORCH TO THE POWER SUPPLY.

☐ **WARNING!** It is the user's responsibility to read, understand and comply with the following electrical instructions:

You must ensure the risk of electric shock is minimised by the installation of appropriate safety devices. An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products, particularly portable equipment which is plugged into an electrical supply not protected by an RCCB.

You must also read and understand the following instructions concerning electrical safety.

**1.3.1. The Electricity At Work Act 1989** requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.

**1.3.2. The Health & Safety at Work Act 1974** makes owners of electrical appliances responsible for the safe condition of the appliance and the safety of the appliance operator. **If in any doubt about electrical safety, contact a qualified electrician.**

#### 1.3.3. You must ensure that you:

- ✓ Inspect the charger plug, cable and connector for wear and damage to ensure items are safe before connecting to the mains power supply. If worn or damaged **DO NOT** use.
- ✓ Important: Check that the voltage marked on the charger plug is the same as the power supply to be used.
- ✓ Uncoil the cable between charger and the lamp.
- ✗ **DO NOT** pull the charger plug from the mains socket by the lead.
- ✗ **DO NOT** use any other type of charger with this product.
- ✗ **DO NOT** try to take the charger plug apart.
- ✗ **DO NOT** use the charger plug to charge or power any other electrical item.
- ✗ **DO NOT** get the charger wet, or use in wet, damp conditions (for indoor use only).
- ☐ **WARNING! NEVER** substitute a standard 13amp 3 pin plug, or any other type of plug, for the charger plug.

## 2. INTRODUCTION

Robust ABS housing featuring 30 super bright LEDs. 360° Swivel hanging hook and heavy-duty magnet for hands-free use. Rocker switch for two light settings. Ideal for use in engine bays, under-body inspections and low light work areas.

## 3. CHARGING

- 3.1 Make sure the lamp is switched off before commencing charging.
- 3.1.1 Plug the charger into the charging socket at the base of the lamp.
- 3.1.2 Plug the transformer plug into the mains supply.
- 3.1.3 Whilst the lamp is charging the bottom LED (Fig.1B) will light up red (Charge time: 3.5 hrs). When fully charged the LED will turn green.
- 3.1.4 When charged unplug the charger from the mains supply. Remove charger lead from the lamp.

**NOTE:** To maintain battery, charge monthly if lamp is not in use.

**NOTE:** LED arrays are designed to allow individual LEDs to cease functioning without causing the entire array to fail. This could be as a result of shock or impact. Shock or impact will invalidate warranty.

## 4. OPERATION

- 4.1 Switch the lamp ON & OFF using the rocker switch (Fig.1C) on the handle. Direct the lens away from your eyes before switching on.
- 4.2 Use the rocker switch to select between the 10 LEDs (9hrs of use) to the 30 LEDs (3.5hrs of use).
- 4.3 Suspend the lamp by the hanging hook. When the light is hanging from its hook it can be rotated through 360° for more precise positioning.
- 4.4 If hanging the lamp is not appropriate you can use the heavy-duty magnet (Fig.1A) on the rear of the lamp at the top of the handle to temporarily fix to any suitable surface.



**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of this product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.

**INFORMATION:** For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

