



RECHARGEABLE ALUMINIUM TORCH - ADJUSTABLE FOCUS

MODEL NO: LED4491.V2, LED4492.V2, LED4493.V2 &
LED4494.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instructions

1. SAFETY

1.1. GENERAL SAFETY

- ☐ **WARNING!** These torches are highly powerful and can get hot very quickly! Please be sure to take care when using and storing the unit.
- ✖ **DO NOT** cover the lens whilst the torch is on and allow sufficient time to cool before storing.
- ✓ Ensure the lamp is fully charged before initial use.
- ✖ **DO NOT** turn the torch on when it is being charged.
- ✖ **DO NOT** shine directly into your, other person's or animal's eyes.
- ✖ **DO NOT** allow children to use the torch.
- ✖ **DO NOT** handle or move the torch whilst it is being charged.
- ✖ **DO NOT** use the torch if you suspect that the battery or the torch casing is damaged.
- ✖ **DO NOT** leave battery in a discharged state, recharge battery immediately. Before storage, fully recharge the battery, subsequently recharge the battery at least once every six months of non-use.

1.2. ELECTRICAL SAFETY

- ✓ Use only the USB charging lead supplied to charge the battery.
- ☐ Inspect the cable and connector for wear and damage to ensure items are safe before connecting to the power supply.
- ✖ **DO NOT** use if worn or damaged.

1.3. BATTERY SAFETY

- ☐ **WARNING!** To reduce the risk of burns or fire:
- ✖ **DO NOT** Attempt to open, disassemble, modify or service the battery pack.
- ✖ **DO NOT** Crush, puncture, short external contacts or dispose of in fire or water.
- ✖ **DO NOT** Expose to temperatures above 60°C (140°F).
- ✓ Replace only with the battery pack designated for this product.
- ✓ Recycle or dispose of used battery as stipulated by local regulation.
- ✓ If the electrolyte in the cells gets on your skin, thoroughly wash with water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

2. INTRODUCTION

Super powerful LEDs produce extremely bright, white light with outputs ranging from 750-4000 lumens and a working range of 100-200m (depending on model). Focus type can be changed from spotlight to wide area by a twist action of the head. Lightweight aluminium housing. Two power options - full power and 30% energy saving mode. Powered by rechargeable lithium-ion batteries.

Strong magnet on the base. Supplied with Type-C USB charging lead.

The battery fitted to this lamp is considered to be a consumable item and its ability to accept a charge will reduce over time.

3. SPECIFICATION

Model No	LED4491.V2	LED4492.V2	LED4493.V2	LED4494.V2
Battery	3.7V 2Ah Lithium-ion	3.7V 2Ah Lithium-ion	7.4V 2Ah Lithium-ion	7.4V 4Ah Lithium-ion
LED Type	5W SMD	10W SMD	20W SMD	60W COB
Lumen Output	High/Low: 900lm/260lm	High: 1200lm/Low: 550lm	High/Low: 2000lm/600lm	High/Low: 4000lm/1200lm
Nett Weight	235g	250g	490g	760g
Operating Time	High/Low: 2hr/4.5hr	High/Low: 1.5hr/3hr	High/Low: 2hr/4hr	High/Low: 2.5hr/6.5hr
Range	High/Low: 180m/100m	High/Low: 200m/150m	200m	High/Low: 170m/90m

We will provide warranty against mechanical and electrical defect for a period of one year - this does not cover fair wear and tear. If the battery is not properly charged before first use, or regularly conditioned, its capacity will diminish. Under these circumstances we will not replace the battery regardless of whether it is less than one year old.

Note: The lithium battery does not suffer from memory effect and once fully charged may be stored for up to six months without another charge.

4. OPERATION

- 4.1. Before first use, unscrew the battery compartment screw cap (fig.1) and remove the white disc from beneath the contact.
- 4.2. The On/Off button will flash red when the battery level becomes low.
- 4.3. Lift up USB cover to reveal USB charging point, where the provided USB charging cable can be inserted.
- 4.4. Plug in the cable to an appropriate power source. Charging will take approximately 3hrs.
- 4.5. When charged remove USB cable and close the USB cover (fig.1).
- 4.6. To switch on press on/off button (side of the torch), press again to change to low beam, press again to switch off (fig.1).
- 4.7. Focus can be adjusted spotlight to wide angle by twisting head of torch (fig.1).

5. MAINTENANCE

- 5.1. Keep the torch clean by wiping with a damp cloth.
- 5.2. Remove batteries if not being used for a long period of time.
- 5.3. Store torch and batteries in a dry childproof area.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk