

Thank you for purchasing a Sealey compressor. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- ✓ Familiarise yourself with the application, limitations and potential hazards of the compressor.
- ❑ **WARNING!** Disconnect the compressor from the cigarette lighter socket before changing accessories, servicing or performing any maintenance.
- ✓ Use only the supplied adaptors.
- ✓ Maintain the compressor in good condition, **DO NOT** use if damaged.
- ✓ Ensure that there are no flammable or combustible materials (including gases) near the compressor when in use.
- ❑ **WARNING!** This compressor is capable of high pressure. **DO NOT** exceed the maximum safe pressure of the item being inflated.
- ❑ **WARNING!** The gauge on the compressor is for guidance only. Where pressure is critical (e.g. tyres) check with a gauge of known accuracy.
- x **DO NOT** leave the compressor operating unattended.
- x **DO NOT** operate in wet or damp conditions.
- ❑ **WARNING!** To prevent overheating and subsequent damage to the unit, switch off after 10 minutes continuous operation and allow to cool for 30 minutes before switching back on.
- ✓ After use store in a safe, dry, childproof area with the connector locking lever in the unlocked position.

2. INTRODUCTION

Sturdy composite casing incorporating cable tidy and plug storage. Powered by a 12V motor and is suitable for inflating tyres on cars, vans and 4x4s. Fitted with an integral gauge that reads up to 17bar/250psi. Supplied with 3mtr power cable with in line rotary power switch and plug for use in a cigarette lighter socket, 450mm high pressure hose with clip on connector and accessory kit including ball needle and adaptors for inflatables.

3. OPERATION


- ❑ **WARNING!** Ensure that you read, understand and apply the Safety Instructions before using the compressor.
- ❑ **WARNING!** Connect **only** to 12V DC supply capable of providing a current of at least 8 amps.

3.1. Tyre inflation

- 3.1.1. Remove the dust cap from the tyre valve and push the connector (A - locking lever in line with connector body as shown) onto the valve as far as it will go. Lock in place by pressing down the locking lever. If air loss can be heard remove the connector and then refit.
- 3.1.2. With the compressor switch (C) off, plug the cigarette lighter adaptor (B) into the vehicle's lighter socket. Note that it may be necessary to turn on the ignition to get power to the lighter socket.
- 3.1.3. Switch on the compressor.
- 3.1.4. When the gauge (E) shows the required pressure (see vehicle handbook) switch off the compressor and unlock and remove the connector (A) from the tyre valve. Refit the tyre valve dust cap.
- 3.1.5. At the first opportunity have the tyre pressure checked with a gauge of known accuracy.

3.2. Inflatables

- 3.2.1. Select the appropriate adaptor from the three provided (D) and secure it in the connector (A).
- 3.2.2. Insert the adaptor (D) into the inflatable and proceed as in 2.1. to connect and start the compressor.
Take care not to over-inflate.



3. TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Compressor does not run.	Poor connection between cigarette lighter plug adaptor and lighter socket. Ignition required to be on to power socket. Socket fuse blown.	Rotate plug in socket to improve contact. Clean out socket. Turn on ignition. Check and replace fuse if necessary.
Compressor runs but does not inflate.	Valve connector or adaptor leaking. Other leaks.	Remove and refit connector or adaptor. Check compressor, connector hose and item being inflated for leaks.
Compressor runs at reduced speed.	Voltage low. Overheating.	Check condition of vehicle battery/charging system. Switch off compressor immediately and leave to cool for 30 minutes.

4. DECLARATION OF CONFORMITY

Declaration of Conformity We, the sole distributor in the UK, declare that the product listed below is in conformity with the following standards and directives.

12V MINI AIR COMPRESSOR
Model MAC1250

89/336/EEC EMC Directive



The construction file for this product is held by the manufacturer and may be inspected, by a national authority, upon request to Jack Sealey Ltd.

Signed by Mark Sweetman

19th August 2002

For Jack Sealey Ltd., sole distributor in the UK of Sealey Power Products.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this equipment.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.

Sole UK Distributor, Sealey Group,
Bury St. Edmunds, Suffolk.



01284 757500



01284 703534

E-mail: sales@sealey.co.uk

Web: www.sealey.co.uk