

# COMMERCIAL PANEL STAND - DOOR, WING, BONNET & BUMPER

MODEL NO: MK59.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

## 1. SAFETY

- ✓ Only use on firm, level, unobstructed surfaces which are capable of supporting the stand and body panels.
- DO NOT overload.
- ✓ Always load evenly with the centre of gravity of the load as near the centre as possible.
- ✓ Apply the brakes before commencing work.
- **DO NOT** stand/ride on the stand, or allow others to do so.
- Replace or repair damaged parts. Use only recommended parts. Unauthorised parts may be dangerous and will invalidate the warranty.
- **WARNING!** Failure to comply with these instructions may result in loss of load, damage to the stand or other property and/or personal injury.
- □ **WARNING!** The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.

#### 2. INTRODUCTION

Suitable for supporting large panels from cars or commercial vehicles. Features fully adjustable arms to fit many styles of bonnets, wings, doors, bumpers and tailgates. Each level can rotate 360° to suit. Fitted with two fixed Ø180mm wheels and two braked castors for manoeuvrability.

## 3. SPECIFICATION

Model No:	MK59.V2
Base Dimensions (W x D):	1150 x 700mm
Maximum Arm Length:	1430mm
Maximum Height:	1600mm
Maximum Capacity:	70kg

#### 4. ASSEMBLY

Assemble panel stand according to the parts diagram attached.

#### 5. OPERATION

- Loosen the knobs and adjust the position of the cross tubes as required.
- 5.2. If required, secure the help of a second person, and lift the vehicle panel into position, find a suitable feature to rest it on the cross tubes.
- 5.3. If further security is required, use chains or similar to attach to a suitable feature on the panel and stretch the chain to the brackets on the oblique tubes and secure. **DO NOT** let go of the panel until you are sure that it is properly secured.





## **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



**Note**: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

1 01284 757500 sales@sealey.co.uk www.sealey.co.uk

© Jack Sealey Limited Original Language Version MK59.V2 Issue 2 20/02/25