

# AUTOMOTIVE TEST DEVICE

## INSTRUCTIONS FOR USE

### SWITCH FUNCTIONS

- Positive on probe - Push switch forward
- Negative on probe - Push switch backwards
- Polarity check - Don't press switch

### TESTING TRAILER LIGHTS

1. Hook up battery clips
2. Attach earth clip to trailer earth
3. Push switch for positive potential
4. Test points as required

### TESTING FOR VOLTAGES

- Hook up battery clips
- Attach earth clip to an **earth**
- Apply probe to point
- Red Led = positive
- Test points as required



### TO ENERGISE COMPONENTS:

- Hook up battery clips
- Apply probe to positive point of component
- Use ground lead to apply ground
- Push switch forward

### TO CHECK CONTINUITY

- Hook up battery clips
- Apply probe to one end
- Apply ground lead to other end
- LED on = continuity

### ENERGISING COMPONENTS OUT OF VEHICLES

- Hook up battery clips
- Apply probe to positive point
- Apply ground lead to other end
- Push switch forward
- If good, component will operate

Sealey Group  
 Bury St Edmunds  
 SUFFOLK  
 ☎ 01284 757500  
 📠 01284 703534  
 ✉ sales@sealey.co.uk  
 🌐 www.sealey.co.uk

Size	Depth	SOLE UK DISTRIBUTOR
181x310mm	45mm	
PLEASE  RECYCLE V2		
Weight	Studio	
0.46kg	122008	