



OUTDOOR STORAGE BOX

MODEL NO: **SBSC01.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear protective gloves

1. SAFETY

1.1. GENERAL SAFETY

- × **DO NOT** overload the box creating excessive forces on box walls or base.
- × **DO NOT** drop loads on to base or items already stored.
- × **DO NOT** use the storage box for any purpose other than that for which it is designed.
- × **DO NOT** stand in or on the storage box.
- × **DO NOT** use to continuously transport stored items from one place to another.
- ✓ Stand the storage box on an accessible flat horizontal plinth or concrete path.
- ✓ Padlock for safety and security.

2. INTRODUCTION

Manufactured from heavy-duty polypropylene, maintenance-free and fully weatherproof. Features hinged lid which can be padlocked (not included) for added security. Fitted with two carry-handles, closed ventilation and two integral wheels on base for easy manoeuvrability. Ideal for use in multiple domestic applications, including garden tool and furniture storage. Supplied flat-packed and can be easily assembled with no tools required.

















3. SPECIFICATION

MODEL NO:..... **SBSC01.V2**
External Size (W x D x H): 1120 x 460 x 540mm
Internal Size (W x D x H): 1100 x 450 x 500mm
Maximum Load: 150kg



4. ASSEMBLY

Carefully unpack the product and check the contents against the diagram and parts list below. Should any items be missing or damaged contact your Sealey stockist.

<p>PARTS LIST:</p>  <p>Front Panel</p>  <p>Back Panel</p>  <p>Lid</p>  <p>Bottom Panel</p>  <p>Right Side</p>  <p>Left Side</p>  <p>Hinge pins (x3)</p>  <p>Lid retainer pins (x2)</p>  <p>Roller (x2)</p>  <p>Handle (x2)</p>  <p>Roller frame (x2)</p>	<p>Step 1 Fix front and rear panels to base panel.</p> 	<p>Step 2 Fix side panels.</p> 
<p>Step 3 Fix the lid to the back panel using the three hinge pins and lid retainers</p> 	<p>Step 4 Locate and snap holes in roller housing over plugs in bottom panel.</p>   <p>Lugs</p>	



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk