

3 GUN CABINET, DUAL KEY LOCK 3 GUN CABINET WITH AMMO SAFE

MODEL NO: SGS3, SGS3AB

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

1. SAFETY

- WARNING! This gun cabinet is heavy and care should be exercised in transit and handling to ensure that no one is injured.
- For maximum security, the gun cabinet must be securely fixed to a floor and/or wall. At all times, and should be positioned on a level floor/surface.
- **DO NOT** install in areas where damp and condensation are present.

2. INTRODUCTION

Features three gun capacity, suitable for rifles and shotguns. Two high security seven lever locks, supplied with two keys per lock. Built to comply with BS7558. Fitted with high density foam gun divider and soft floor mat to prevent any damage to stored guns. Manufactured with thick steel walls and door with a powder coated finish. Supplied with a set of fixings to secure the cabinet in place.

3. SPECIFICATION

Model No:	SGS3	SGS3AB
Gun Capacity:	3	3
External Dimensions (W x D x H):	245 x 205 x 1255mm	245 x 205 x 1450mm
Internal Dimensions (W x D x H):	240 x 175 x 1250mm	240 x 175 x1265mm
Nett Weight:	24.5kg	29kg

4. UNPACKING AND INSTALLATION

- 4.1. Carefully remove all parts from the packaging.
- 4.2. Verify that all components are included:
 - Gun cabinet body.
 - Locking mechanism (keys).
 - Mounting hardware.
 - User manual

4.3. INSTALLATION INSTRUCTIONS (fig. 1)

- 4.3.1. Choose a location that is dry and secure.
- 4.3.2. Position the cabinet against a solid wall or floor.
- 4.3.3. Use the provided mounting hardware or other suitable hardware to anchor the cabinet to the wall or floor.
- 4.3.4. Ensure the cabinet is level and does not wobble.
- 4.3.5. Double-check the installation for stability before use.


4.4. LOCKING AND UNLOCKING MECHANISM

- 4.4.1. Insert the key and turn clockwise to unlock.
- 4.4.2. To lock, close the door and turn the key counterclockwise.

5. MAINTENANCE

- 5.1. Periodically check locks and hinges for smooth operation.
- 5.2. Wipe down the interior and exterior with a dry or slightly damp cloth.
- 5.3. Lubricate lock mechanisms as needed.
- 5.4. Inspect the cabinet for rust or damage and address any issues immediately.
- 5.5. STORAGE GUIDELINES
- 5.6. Arrange firearms with muzzles pointing upward or downward, never sideways.
- DO NOT overcrowd the cabinet; this may damage firearms or prevent proper door closure.
- 5.7. If storing ammunition, keep it in a separate, secured compartment.
- 5.8. Use silicone-treated gun socks or desiccants to reduce moisture build up.





Parts support is available for this product. To obtain parts, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500

ENVIRONMENT PROTECTION



Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

SGS3 SGS3AB Issue 1 14/02/25