



Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY INSTRUCTIONS

- 1.1. ELECTRICAL SAFETY. ⚠ WARNING! It is the user's responsibility to read, understand and comply with the following:**
You must check all electrical equipment and appliances to ensure they are safe before using. *You must* inspect power supply leads, plugs and all electrical connections for wear and damage. *You must* ensure the risk of electric shock is minimised by the installation of appropriate safety devices. An RCCB (Residual Current Circuit Breaker) should be incorporated in the main distribution board. We also recommend that an RCD (Residual Current Device) is used with all electrical products. It is particularly important to use an RCD together with portable products that are plugged into an electrical supply not protected by an RCCB. If in doubt consult a qualified electrician. You may obtain a Residual Current Device by contacting your Sealey dealer. *You must* also read and understand the following instructions concerning electrical safety.
- 1.1.1. The **Electricity At Work Act 1989** requires all portable electrical appliances, if used on business premises, to be tested by a qualified electrician, using a Portable Appliance Tester (PAT), at least once a year.
- 1.1.2. The **Health & Safety at Work Act 1974** makes owners of electrical appliances responsible for the safe condition of the appliance and the safety of the appliance operator. **If in any doubt about electrical safety, contact a qualified electrician.**
- 1.1.3. Ensure the insulation on all cables and the product itself is safe before connecting to the mains power supply. See 1.1.1. & 1.1.2. above and use a Portable Appliance Tester (PAT).
- 1.1.4. Ensure that cables are always protected against short circuit and overload.
- 1.1.5. Regularly inspect power supply, leads, plugs for wear and damage and connections, to ensure that none is loose.
- 1.1.6. **Important:** Ensure the voltage marked on the product is the same as the electrical power supply to be used, and check that plugs are fitted with the correct capacity fuse. A 13 amp plug may require a fuse smaller than 13 amps for certain products (*subject to 1.1.10. below*), see fuse rating at right.
- 1.1.7. DO NOT pull power plugs from sockets by the power cable.
- 1.1.8. DO NOT use worn or damage leads, plugs or connections. Immediately replace or have repaired by a qualified electrician. A U.K. 3 pin plug with ASTA/BS approval is fitted. In case of damage, cut off and fit a new plug according to the following instructions (discard old plug safely). (UK only - see diagram at right). **Ensure the unit is correctly earthed via a three-pin plug.**
- a) **Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.**
 - b) **Connect the BROWN live wire to live terminal 'L'.**
 - c) **Connect the BLUE neutral wire to the neutral terminal 'N'.**
- After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable outer insulation extends beyond the cable restraint and that the restraint is tight.**
- Double insulated products are often fitted with live (BROWN) and neutral (BLUE) wires only. Double insulated products are always marked with this symbol . **To re-wire, connect the brown and blue wires as indicated above. DO NOT connect the brown or blue to the earth terminal.**
- 1.1.9. Some products require more than a 13 amp electrical supply. In such a case, **NO** plug will be fitted. *You must* contact a qualified electrician to ensure a 30 amp fused supply is available. We recommend that you discuss the installation of a industrial round pin plug and socket with your electrician.
- 1.1.10. **Cable extension reels.** When a cable extension reel is used it should be fully unwound before connection. A cable reel with an RCD fitted is recommended since any product which is plugged into the cable reel will be protected. The section of the cable on the cable reel is important. We recommend that at least 1.5mm² section cable but to be absolutely sure that the capacity of the cable reel is suitable for this product and for others that may be used in the other output sockets, we recommend the use of 2.5mm² section cable.



1.2 GENERAL SAFETY

- ⚠ **WARNING!** Disconnect the collector from the mains power and ensure the impeller is at a complete standstill before attempting to change accessories, service or perform any maintenance.
- ✓ Maintain the collector in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. *Use recommended parts only. Non-authorized parts may be dangerous and will invalidate the warranty.*
- ✓ Locate the collector in a suitable working area. Ensure the surface is flat and firm. Keep area clean and tidy and free from unrelated materials, and ensure there is adequate lighting.
- ✓ Keep the collector clean for best and safest performance and check moving parts alignment regularly.
- ✓ Remove any tools from the collector and the vicinity before turning it on.
- ⚠ **WARNING!** Wear approved safety eye protection, ear defenders, and gauntlets, and, if dust is generated, respiratory protection.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and contain long hair.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Keep children and unauthorised persons away from the working area.
- x **DO NOT** use the collector for any purpose other than that for which it is designed. **DO NOT** pick up glass, metal or water.
- x **DO NOT** allow untrained persons to operate the collector.
- x **DO NOT** get the unit wet or use in damp or wet locations or areas where there is condensation.
- ⚠ **WARNING! DO NOT** use collector where there are flammable liquids, solids or gases such as petrol, paint solvents, waste wiping rags etc.
- x **DO NOT** operate the collector if any parts are missing or damaged as this may cause failure and/or personal injury.
- x **DO NOT** operate the collector when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ✓ When not in use switch the collector off and isolate from the power supply.


2. APPLICATION & SPECIFICATION

Mobile economy dust collector suitable for attachment to most static workshop machines including bandsaws, table saws, scroll saws, planers and sanders. Contoured, textured handle for added manoeuvrability. Supplied with dust collection bag, bag-clamp, BS approved 3 pin plug and cable.

The SM1309 is designed to extract dust, saw dust and other fine debris from wood machining. It **should not** be used to extract metallic debris, glass or water.

Specification:

Capacity	914cfm
Intake diameter.....	100mm
Fan diameter	152mm
Motor	230V, 50Hz, 750W



3. ASSEMBLY

- 3.1. Attach the four castors (A) to the underside of the base using washers (C) and nuts (B).
- 3.2. Fit collector bag over outlet and secure with clamp.

4. OPERATING INSTRUCTIONS

- WARNING! Before operating the collector ensure that you read, understand and apply the safety instructions in Section 1.**
- 4.1. Confirm that supply voltage matches the voltage shown on the motor data plate and that the motor switch is 'Off'.
- 4.2. Connect collector hose to the inlet on the collector body and attach other end to collector point on equipment.
- WARNING! DO NOT operate collector without the hose attached.**
- 4.3. Plug into mains supply and press motor switch 'On'.
- 4.4. Ensure that the collector bag is emptied of dust and chips on a regular basis and is not allowed to become full.



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.



Sole UK Distributor, Sealey Group,
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk,
IP32 7AR

01284 757500
01284 703534

www.sealey.co.uk
sales@sealey.co.uk