SEALEY

2L PRESSURE POT FOR SSG1P

MODEL NO: SSG1P/3.V3

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY.



Refer to instruction manual

1. SAFETY

- ✓ Familiarise yourself with the application, limitations and potential hazards peculiar to the spray gun.
- WARNING! Disconnect the spray gun from the air supply before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the spray gun in good condition (use an authorised service agent).
- Replace or repair damaged parts. Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Keep the spray gun clean for best and safest performance.
- Ensure that the compressed air system can supply the spray gun air consumption (7-12cfm).
- ✓ Wear approved safety respiratory protection and safety eye goggles.
- ✓ If spraying isocyanate based finisher, wear approved respirator/clean air breathing apparatus and
 protect skin with latex gloves and an impervious hooded coverall.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and tie back long hair.
- Locate the spray gun in a suitable work area. Keep area clean and tidy and free from unrelated materials and ensure that there is adequate ventilation and lighting.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ When not in use, ensure that the air supply is turned off.
- ✓ Avoid unintentional operation of spray gun.
- **DO NOT** point spray gun at yourself, other persons or animals.
- DO NOT direct air from the air hose at yourself, other persons or animals.
- DO NOT carry the spray gun by the hose, or pull the hose from the air supply.
- **DO NOT** exceed the maximum air pressure of 78psi.
- **DO NOT** use the spray gun for any purpose other than that for which it is designed.
- **DO NOT** allow untrained persons to operate the spray gun.
- **DO NOT** get the spray gun wet or use in damp or wet locations or in areas where there is condensation.
- DO NOT operate the spray gun if any parts are missing or damaged as this may cause failure and/or personal injury.
- ✓ When not in use, disconnect the spray gun from the air supply, clean thoroughly and store safely.

2. INTRODUCTION

Pressure pot suitable for use with Model No. SSG1P Pressure Pot Spray Gun.

3. SPECIFICATION

Model No: SSG1P/3.V3
Description: 2L Pressure Pot

4. ASSEMBLY

- **4.1.** Connect the air and paint hoses in the following manner.
 - a: Blue air hose from pressure regulator to gun handle.
 - b: Clear hose from Pot paint outlet to inlet on underside of nozzle on gun.
- **4.2.** Initially screw parts hand tight to avoid cross-threading. If a part cannot easily be turned by hand, check that you have the correct part, or unscrew, realign and try again. **DO NOT** use excessive force when assembling.

5. CLEANING/MAINTENANCE

- □ WARNING! Disconnect from the air supply before attempting any maintenance or cleaning.
- **5.1.** When finished spraying, wipe the outside of the pot and fittings with a dampened solvent rag.



Parts support is available for this product. Please email sales@sealey.co.uk or telephone 01284 757500



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

© Jack Sealey Limited Original Language Version SSG1P-3.V3 Issue 1 11/10/21