



LOCKING WHEEL NUT KEY SET

10PC - BMW & MINI

MODEL NO: **SX208.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instruction
manual

1. SAFETY

- ☐ **WARNING! DO NOT** use the tool if damaged or thought to be faulty.
- ☐ **WARNING!** Ensure that Health & Safety, Local Authority Regulations and general workshop practice Regulations are adhered to when using tools.
- ☐ **WARNING!** If jacking up a vehicle refer to manufactures instructions for vehicle and jack.
- ☒ **DO NOT** use the tool for a task it is not designed to perform.
- ☒ **DO NOT** use worn, or damaged sockets.
- ☒ **DO NOT** use the tool unless you have been instructed in its use by a qualified person.
- ☒ **DO NOT** operate the tool if you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ☒ Maintain the tool in good condition.
- ☒ Follow all workshop safety rules, regulations and conditions.
- ☒ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ☒ Keep children and non essential persons away from the working area.

2. INTRODUCTION

Set of 10 locking keys for the removal of security splined locking wheel nuts on BMW and Mini. For distribution to bona fide vehicle dealers and repair centres only.

3. CONTENTS

Component	Description
SX208.V2-30.13PT	Locking Wheel Nut Key, BMW/Mini #30/13PT
SX208.V2-31.15PT	Locking Wheel Nut Key, BMW/Mini #31/15PT
SX208.V2-32.16PT	Locking Wheel Nut Key, BMW/Mini #32/16PT
SX208.V2-33.17PT	Locking Wheel Nut Key, BMW/Mini #33/17PT
SX208.V2-34.18PT	Locking Wheel Nut Key, BMW/Mini #34/18PT
SX208.V2-35.19PT	Locking Wheel Nut Key, BMW/Mini #35/19PT
SX208.V2-36.20PT	Locking Wheel Nut Key, BMW/Mini #36/20PT
SX208.V2-37.21PT	Locking Wheel Nut Key, BMW/Mini #37/21PT
SX208.V2-38.22PT	Locking Wheel Nut Key, BMW/Mini #38/22PT
SX208.V2-40.23PT	Locking Wheel Nut Key, BMW/Mini #40/23PT



4. OPERATION

- 4.1. Choose correct locking wheel nut key for vehicle.
- 4.2. Place the key over the wheel nut/bolt and rotate until the key slots into the wheel bolt/nut.
- 4.3. Attach either a 17mm socket plus drive to the key and turn anti-clockwise to remove wheel bolt/nut.
- 4.4. To replace bolt/nut reverse removal operation. Use torque wrench to tighten.

5. MAINTENANCE

- 5.1. Keep keys clean and store in case provided.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk