

Thank you for purchasing a Sealey product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

! **IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.**

1. SAFETY INSTRUCTIONS

Before fitting the towball lock ensure that the trailer/caravan is stable and braked or securely chocked.

2. FEATURES

- Fits Ø50mm towing sockets and prevents unauthorised use.
- Rotating barrel lock improves security.
- Easy to fit and unobtrusive.

3. OPERATION

- 4.1. Using the key (two provided) unlock and remove the barrel lock.
- 4.2. Insert the towball lock into the trailer coupling (fig. 1) and use the hex. key provided to expand the lock until it is firmly held in the coupling (fig. 2).
- 4.3. Insert the barrel lock, turn the key to lock it in place and then remove key (fig. 3).
- 4.4. To remove the towball lock reverse the above procedure.




fig. 1




fig. 2




fig. 3

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this equipment.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address, including postcode.