SEALEY

DRUM & BARREL TROLLEY

MODEL NO: TP13

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual

1. SAFETY

- \checkmark Always position drum/barrel at the rear of the cradle before attempting to move the trolley.
- **DO NOT** load more than one drum/barrel.
- **DO NOT** overload the trolley maximum capacity is **350kg**.
- **DO NOT** allow others to ride on the trolley.
- Only use the trolley on firm, level, unobstructed surfaces which are capable of supporting the trolley and wheel.
- DO NOT use on tarmacadam. The trolley must only be used on a concrete surface.
- Replace or repair damaged parts. Use only recommended parts. Unauthorised parts may be dangerous and will invalidate the warranty.
- □ WARNING! Failure to comply with these instructions may result in loss of load, damage to trolley or other property and/or personal injury.

2. INTRODUCTION

Rigid steel construction suitable for safe movement and storage of steel and plastic barrels. Cradle fitted with two, smooth-rolling, heavy-duty, Ø150mm wheels and one Ø75mm castor. 2-Position handle locks upright or at 45° and features tools for five different drum caps and a metal drum tilting attachment.

3. SPECIFICATION

 Model No:
 TP13

 Load Capacity:
 350kg

4. ASSEMBLY

Refer to Parts List

4.1. Insert handle.

5. OPERATION

- 5.1. Position the trolley in front of the drum.
- 5.2. Remove the handle from the trolley and use it to tilt the drum.
- 5.3. Push the trolley cradle under the tilted drum.
- 5.4. Refit the handle to the trolley and transport drum.

6. MAINTENANCE

- 6.1. Daily: check for damage.
- 6.2. Monthly: oil wheels.





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

1 01284 757500 01284 703534 | sales@sealey.co.uk | www.sealey.co.uk

© Jack Sealey Limited Original Language Version TP13 Issue:3 (3) 29/07/22