



INSTRUCTIONS FOR: TYRE STACK

MODEL: TS4

Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.



PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL IMPORTANT: REQUIREMENTS. WARNINGS AND CAUTIONS. USE THIS PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY. AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

SAFETY INSTRUCTIONS

☐ WARNING! Use the tyre stack on level & solid ground, preferably concrete. Avoid soft surfaces as the stack may sink in and subsequently topple over.

- ✓ Replace or repair damaged parts. Use genuine parts only. Non authorised parts may be dangerous and will invalidate the warranty.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- ✓ Keep children and unauthorised persons away from the working area.
- Maintain correct balance and footing. Ensure the floor is not slippery and wear non slip shoes.
- X DO NOT use the tyre stack for any purpose other than for which it is designed.
- X DO NOT use the tyre stack if any parts are damaged or missing as this may cause failure or possible personal injury.




INTRODUCTION

The TS4 provides safe storage of up to four tyres and rims once removed from the vehicle. Prevents scuffing and damage to expensive alloy wheel rims. Frame folds for compact storage out of use. Suitable for tyres up to 225mm wide. Ideal for both workshop and bodyshop.

ASSEMBLY AND USE

- 3.1. Unfold the four feet so that the base sits flat on the ground.
- 3.2. Insert the two uprights, fig.1, A & B.
- 3.3. Insert a wheel plate locating bar, fig.1.C, in the lowest available hole before adding the wheel plate, fig.2.A.
- 3.4. The tyre stack is now ready to accept a
- 3.5. Repeat paragraph 3.3 for each wheel to be stacked.
- 3.6. Reverse the above procedure to remove the wheels from the stack.





NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of this equipment. WARRANTY: Guarantee is 12 months from purchase date. proof of which will be required for any claim. INFORMATION: For a copy of our latest catalogue and promotions, call us on 01284 757525 and leave your full name and address including your postcode.



Sole UK Distributor, Sealey Group, Bury St. Edmunds, Suffolk.



111 01284 757500



01284 703534

E-mail: sales@sealey.co.uk