

ROVER 75 APPLICATION

In order to ensure correct operation on Rover 75 models it is necessary to carry out the following procedure.

1. **Connect the reset unit to the multifit lead and set the lead switches to F2. DO NOT connect to the vehicle at this time.**
2. **Switch on the vehicle ignition.**
3. **Wait ten seconds.**
4. **Connect the reset unit to the vehicle connector.**
5. **Carry out the reset procedure as described in the Instructions, paras. 5.4. and 5.5.**

Notes:

- a. **If more than one function is to be reset, the above procedure, from 2 to 5, must be carried out for each one.**
- b. **If the lead switches have been incorrectly set, restart the procedure from the beginning.**

