

SEALEY

GASKET SEPARATOR AND CLEANING KIT 21PC

MODEL NO: **VS655**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instruction
manual



Wear eye
protection



Wear protective
gloves

1. SAFETY


- ✓ Always read the instructions carefully before using the tool.
- ✓ Ensure the working area has adequate lighting
- ✓ Keep children and unauthorized persons away from the working area.
- ✓ Keep working area clean and tidy, dry and free from unrelated materials
- ✗ **DO NOT** allow untrained persons to use this tool kit
- ✓ Always wear adequate PPE: eye protection and gloves, when working with the tool.

2. INTRODUCTION

Designed for the separation and removal of sumps on engines and gearboxes. Can also be used on other sealed applications such as cylinder heads, differentials, and transfer boxes. Cleaning pads for the quick removal of sealant or gasket residue left on surface area. Supplied with a steel head for harder surfaces and a bronze head for softer surfaces reducing the risk of damage.

3. CONTENTS

Refer to attached Parts Information sheet.



4. OPERATION

- 4.1. Select blade to suit oil pan material and fit blade and handle to the tool, Fig.1. Handle can be fitted in different positions when space is limited, Figs 2 & 3.
- 4.2. Hold tool and use a hammer to remove sealant on the oil pan, Fig.2. Fit a cleaning pad to the extension bar and use a drill to clean residual sealant from the oil pan lip.



Fig 1




Fig 2




Fig 3

5. MAINTENANCE

- 5.1. Clean residual sealant from all components.
- 5.2. Replace components into the case. Store in a dry, child free area.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.



REGISTER YOUR
PURCHASE HERE

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk