
SEALEY

THE TOOL COMPANY

PARTS INFORMATION

# Heavy-Duty Floor Transmission Jacks

## Model No. 1500E.V2



| Item | Part No. | Description |
|---|---|---|
| 1 | 1500E.V2-01 | Wheel, Swivel Castor, Single Bolt (D:100 W:35 B:12 H:165) |
| 2 | SWM16.SB | Spring Washer M16 Black |
| 3 | SN16.S | Steel Nut M16 Zinc |
| 4 | 1500E.V2-04 | Frame |
| 5 | 1500E.V2-05 | Shaft |
| 6 | 1500E.V2-06 | Shaft |
| 7 | 1500E.V2-07 | Snap Ring |
| 8 | 1500E.V2-08 | Connecting Bar |
| 9 | 1500E.V2-09 | Snap Ring |
| 10 | 1500E.V2-10 | Bracket |
| 11 | 1500E.V2-11 | Shaft |

| Item | Part No. | Description |
|---|---|---|
| 12 | 1500E.V2-12 | Snap Ring |
| 13 | 1500E.V2-13 | Bracket |
| 14 | 1500E.V2-14 | Nut |
| 15 | 1500E.V2-15 | Bolt |
| 16 | 1500E.V2-16 | Pin |
| 17 | 1500E.V2-17 | Screw |
| 18 | 1500E.V2-18 | Knob, Metal, OD: 76mm L: 36mm, 14mm Female Fitting |
| 19 | 1500E.V2-19 | Lead Screw |
| 20 | 1500E.V2-20 | Nut With Thread For Allen Key |
| 21 | 1500E.V2-21 | Shaft |
| 22 | AK4567D.18 | External Circlip 32.0mm ID. |

© Jack Sealey Limited

# Heavy-Duty Floor Transmission Jacks

THE TOOL COMPANY

## Model No. 1500E.V2

| Item | Part No. | Description |
|---|---|---|
| 23 | 1500E.V2-23 | Circular Nut |
| 24 | B/51102 | Bearing Race 51102 |
| 25 | 1500E.V2-25 | Bushing |
| 26 | 1500E.V2-26 | Shaft |
| 27 | 1500E.V2-27 | Shaft |
| 28 | GNM19S | Grease Nipple Str 6 x 1.00mm Single |
| 29 | 1500E.V2-29 | Arm |
| 30 | 1500E.V2-30 | Pin |
| 31 | 1500E.V2-31 | Shaft |
| 32 | 1500E.V2-32 | Rod Link |
| 33 | 1500E.V2-33 | Snap Ring |
| 34 | 1500E.V2-34 | Connecting Block |
| 35 | 1500E.V2-35 | Pin |
| 1-1 | 1500EV2.1-1 | Retaining Ring |
| 1-2 | 1500EV2.1-2 | Bushing |
| 1-3 | SBJ10W.11 | O-Ring, (Ex: 49.92 In: 42.86 Cs: 3.53) |
| 1-4 | 1500EV2.1-4 | Piston Rod |
| 1-5 | 1500EV2.1-5 | Piston Ring |
| 1-6 | 1500EV2.1-6 | Sealing Washer |
| 1-7 | 1000E.V2-35 | O-Ring, (Ex: 44.95 In: 34.29 Cs: 5.33) |
| 1-8 | 1500EV2.1-8 | Steel Ring |
| 1-9 | 1500EV2.1-9 | Snap Ring |
| 1-10 | 1500EV2.1-10 | Hydraulic Unit |
| 1-11 | 1500EV2.1-11 | Oil filler Plug |
| 1-12 | 1500EV2.1-12 | Bushing |
| 1-13 | 1500EV2.1-13 | Bolt |
| 1-14 | 1500EV2.1-14 | Screw |
| 1-15 | 1500EV2.1-15 | Steel ball |
| 1-16 | 1500EV2.1-16 | O-Ring |
| 1-17 | SB-6.4 | Steel Ball 6.4mm |
| 1-18 | SA316.10 | O-Ring, (Ex: 12.83 In: 7.59 Cs: 2.62) |
| 1-19 | 1500EV2.1-19 | Oil Release Valve Rod |
| 1-20 | HPT1000.108 | Spring Pin M4 X 20 Zinc |

| Item | Part No. | Description |
|---|---|---|
| 1-21 | 1500EV2.1-21 | Knob, Metal, Red, OD: 60mm L: 34mm ID: 10mm, Female Fitting, |
| 1-22 | GSM66.S | Grub Screw m6x6 (Single) |
| 1-23 | 1500EV2.1-23 | Steel Ball |
| 1-24 | 1500EV2.1-24 | Ball Seat |
| 1-25 | 1500EV2.1-25 | Spring |
| 1-26 | 1500EV2.1-26 | Screw |
| 1-27 | 1500EV2.1-27 | Sealing Washer |
| 1-28 | 1500EV2.1-28 | Bolt |
| 1-29 | 1500EV2.1-29 | Spring |
| 1-30 | 1500EV2.1-30 | Steel Ball |
| 1-31 | 1500EV2.1-31 | Spring |
| 1-32 | 1500EV2.1-32 | Copper Washer |
| 1-33 | 1500EV2.1-33 | Bolt |
| 1-34 | 1500EV2.1-34 | Copper Washer Thin M18 |
| 1-35 | 1500EV2.1-35 | E-Clip 7.8mm. |
| 1-36 | 1500EV2.1-36 | Pump Seat |
| 1-37 | 1500EV2.1-37 | Pin |
| 1-38 | 1500EV2.1-38 | Y-Seal |
| 1-39 | 1500EV2.1-39 | O-Ring, (Ex: 17.88 In: 13.20 Cs: 2.34) |
| 1-40 | 1500EV2.1-40 | Pump Plunger |
| 1-41 | 1500EV2.1-41 | Pump Cylinder |
| 1-42 | 1500EV2.1-42 | Dustproof Seal |
| 1-43 | 1500EV2.1-43 | Rod Joint |
| 1-44 | 1500EV2.1-44 | Pin |
| 1-45 | 1500EV2.1-45 | Jack Handle, Red (c/w Grip) Ø22 x 910mm (Flat Plate 96 x 36 x 13mm) |
| 1-46 | 1500EV2.1-46 | Handle Grip For Jack Handle |
| 3-1 | SCB825.SB | Socket Cap Bolt M8 x 25mm Black |
| 3-2 | SWM6.SB | Spring Washer M6 Black |
| 3-3 | FWM6.S | Flat Washer M6 Zinc |
| 3-4 | 1500EV2.3-4 | Chain |
| 3-5 | 1500EV2.3-5 | 5/16 unc Half Nut |
| 3-6 | 1500EV2.3-6 | Screw |
| 3-7 | 1500EV2.3-7 | Saddle Angle |

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See www.sealey.co.uk for the latest information.
**Important:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person.

**Jack Sealey (EU) Ltd t/a Sealey Group** Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
**Jack Sealey Ltd t/a Sealey Group** Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
**Tel:** 01284 757500 ▪ **Email:** sales@sealey.co.uk ▪ **Web:** www.sealey.co.uk

© Jack Sealey Limited

# Heavy-Duty Floor Transmission Jacks

## Model No. 1500E.V2

| Item | Part No. | Description |
|---|---|---|
| 3-8 | 1500EV2.3-8 | Saddle Base |
| 3-9 | 1500EV2.3-9 | Washer |
| 3-10 | SN12.SW | Wing Nut M12 Zinc |
| 3-11 | SN10.S | Steel Nut M10 Zinc |
| 3-12 | FWM10.S | Flat Washer M10 Zinc |
| 3-13 | 1500EV2.3-13 | Saddle Angle |

| Item | Part No. | Description |
|---|---|---|
| 3-14 | SN8.SW | Wing Nut M8 Zinc |
| 3-15 | 1500EV2.3-15 | Guide Screw |
| 3-16 | 1500EV2.3-16 | Hook Bolt |
| 3-17 | MSP612.S | Machine Screw Pan Head Phillips M6 X 12mm |
| 3-18 | 1500EV2.3-18 | Middle Plate For Saddle Base |

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. See www.sealey.co.uk for the latest information.
**Important:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person.

**Jack Sealey (EU) Ltd t/a Sealey Group** Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
**Jack Sealey Ltd t/a Sealey Group** Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
**Tel:** 01284 757500 ▪ **Email:** sales@sealey.co.uk ▪ **Web:** www.sealey.co.uk

© Jack Sealey Limited