



Item	Part No.	Description
1	SMIG140.27	Handle Frame
2	160XT.02	Case
3	140XT.03	Back Panel
4	140XT.04	Fan
5	140XT.05	Bottom Panel
6	160XT.06	Front Panel
7	250XTD.28	Cable Holder
8	140XT.08	Work Clamp
9	140XT.09	Electrode Holder Cable
10	140XT.11	Switch, Rocker (Red)
11	140XT.12	Indicator
12	140XT.13	Hand Wheel

Item	Part No.	Description
13	140XT.14	Pointer
14	140XT.15	Shunt Bracket
15	140XT.16	Shunt
16	140XT.17	Clip
17	140XT.18	Lead Screw Pin
18	140XT.19	Heat Relay
19	140XT.20	Heat Conductor
20	160XT.21	Transformer
21	140XT.22	Transparent Plate
22	140XT.23	Frame
23	140XT.V2-24	Heat Relay
--	140XT.24	Chipping Hammer/Wire Brush (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.