


PARTS LIST FLOOR TRANSMISSION JACK Model: 800CE

Original Date:- 230999
Issue Date:-
Version Nbr:- 0
Date Modified:- N/A



ITEM	PART NO	DESCRIPTION
1	800CE/01	HYDRAULIC UNIT
2	800CE/02	FRAME SET
3	800CE/03	SPRING WASHER
4	800CE/04	HEX. SCREW
5	800CE/05	BRACKET CASTOR WHEEL
6	800CE/06	WASHER
7	800CE/07	HEX NUT
8	800CE/08	ROD, LINK
9	800CE/09	BOLT
10	800CE/10	SPRING WASHER
11	800CE/11	HEX. NUT
12	800CE/12	LIFT ARM SET
13	800CE/13	AXLE, LIFT ARM
14	800CE/14	C-SNAP
15	800CE/15	BASE, PULLING BAR
16	800CE/16	PIN
17	800CE/17	C-SNAP
18	800CE/18	OIL PLUG
19	800CE/19	ADJUST SADDLE
20	800CE/20	C-SNAP
21	800CE/21	SADDLE HOLDER
22	800CE/22	AXLE HOLDER SADDLE
23	800CE/23	E-SNAP
24	800CE/24	ADJUST SCREW BAR
25	800CE/25	BEARING
26	800CE/26	BOLT
27	800CE/27	WASHER
28	800CE/28	NYLON NUT
29	800CE/29	ADJUST SCREW
30	800CE/30	PLATE
31	800CE/31	AXLE, SADDLE
32	800CE/32	C-SNAP
33	800CE/33	ANGLE PLATE ASS'Y
34	800CE/34	WASHER
35	800CE/35	HEXAGON SCREW
36	800CE/36	LEFT PLATE
37	800CE/37	RIGHT PLATE
38	800CE/38	HEX SCREW
39	800CE/39	WASHER
40	800CE/40	HEX NUT
41	800CE/41	L-LOCK SCREW
42	800CE/42	BUTTERFLY SCREW, NUT
43	800CE/43	SHACKLE
44	800CE/44	CHAIN
45	800CE/45	SHACKLE BOLT
46	800CE/46	BUSHING