



Item	Part No.	Description
1	BBQ02.01	HANDLE (TOP)
2	BBQ02.02	GRILL TOP
3	BBQ02.03	LID BRACKET
4	BBQ02.04	GRILL (LSA)
5	BBQ02.05	CHARCOAL GRATE
6	BBQ02.06	SIDE HANDLE
7	BBQ02.07	FIREBOWL
8	BBQ02.08	ASH VENT
9	BBQ02.09	LEG SUPPORT
10	BBQ02.10	LEG (SHORT)

Item	Part No.	Description
11	BBQ02.11	WHEEL, FIXED (146x8x30)
12	BBQ02.12	AIR VENT
13	BBQ02.13	WIRE RACK, LOWER
14	BBQ02.14	LEG (LONG)
15	BBQ02.15	ASH TRAY
A	BBQ02.A	SCREW/NUT/WASHER (4x8mm)
B	BBQ02.B	SCREW/NUT/WASHER (5x10mm)
C	BBQ02.C	LOCK NUT/WASHER (6mm)
D	LS1050V.27	WASHER M6
--	BBQ02.FK	FIXING KIT (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.