
### Parts Information:

# 550W Cement Mixer with Stand 135L

**Model No: CMX135** 



**NOTE**: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR











## Parts Information:

## 550W Cement Mixer with Stand 135L **Model No: CMX135**

| 1     CMX135-01     Drum 135L (for CMX135 only)     1       2     SN10.S     Steel Nut M10 Zinc     4       3     SWM10.S     Spring Washer M10 Zinc     4       4     FWM10.S     Flat Washer M10 Zinc     4       5     CMX135-05     Leather Washer Ø10     4       6     BHSS1025.S     Button Head Socket Screw M10 X 25     4       7     CMX135-07     Mixing Blade (for CMX135 only)     2       8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     8       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washe   | Item | Part No.   | Description                      | Qty |
|---|------|------------|----------------------------------|-----|
| 3     SWM10.S     Spring Washer M10 Zinc     4       4     FWM10.S     Flat Washer M10 Zinc     4       5     CMX135-05     Leather Washer Ø10     4       6     BHSS1025.S     Button Head Socket Screw M10 X 25 Zinc     4       7     CMX135-07     Mixing Blade (for CMX135 only)     2       8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     8       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head S   | 1    | CMX135-01  | Drum 135L (for CMX135 only)      | 1   |
| 4     FWM10.S     Flat Washer M10 Zinc     4       5     CMX135-05     Leather Washer Ø10     4       6     BHSS1025.S     Button Head Socket Screw M10 X 25 Zinc     4       7     CMX135-07     Mixing Blade (for CMX135 only)     2       8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     8       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20 <t< td=""><td>2</td><td>SN10.S</td><td>Steel Nut M10 Zinc</td><td>4</td></t<>          | 2    | SN10.S     | Steel Nut M10 Zinc               | 4   |
| 5     CMX135-05     Leather Washer Ø10     4       6     BHSS1025.S     Button Head Socket Screw M10 X 25 Zinc     4       7     CMX135-07     Mixing Blade (for CMX135 only)     2       8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     14       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle   | 3    | SWM10.S    | Spring Washer M10 Zinc           | 4   |
| 6     BHSS1025.S     Button Head Socket Screw M10 X 25 Zinc     4       7     CMX135-07     Mixing Blade (for CMX135 only)     2       8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     14       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Spring Washe   | 4    | FWM10.S    | Flat Washer M10 Zinc             | 4   |
| Zinc       7     CMX135-07     Mixing Blade (for CMX135 only)     2       8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     14       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S   | 5    | CMX135-05  | Leather Washer Ø10               | 4   |
| 8     SN6.S     Steel Nut M6 Zinc     6       9     SWM6.S     Spring Washer M6 Zinc     8       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc  | 6    | BHSS1025.S |                                  | 4   |
| 9     SWM6.S     Spring Washer M6 Zinc     14       10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw S   | 7    | CMX135-07  | Mixing Blade (for CMX135 only)   | 2   |
| 10     FWM6.S     Flat Washer M6 Zinc     14       11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End P   | 8    | SN6.S      | Steel Nut M6 Zinc                | 6   |
| 11     CMX135-11     Leather Washer Ø6     6       12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-27     Motor End Plate     1       27     CMX135-27     Motor Seat <td>9</td> <td>SWM6.S</td> <td>Spring Washer M6 Zinc</td> <td>8</td>                   | 9    | SWM6.S     | Spring Washer M6 Zinc            | 8   |
| 12     CMX135-12     Cogwheel (Large)     1       13     SS625.S     Hex Head Set Screw M6 X 25 Zinc     6       14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-27     Motor Seat     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30  | 10   | FWM6.S     | Flat Washer M6 Zinc              | 14  |
| 13   SS625.S   Hex Head Set Screw M6 X 25 Zinc   6     14   SS620.S   Hex Head Set Screw M6 X 20 Zinc   2     15   CMX135-15   Plastic Rotator   1     16   NLN8.S   Nyloc Nut M8 Zinc   6     17   FWM8.S   Flat Washer M8 Zinc   8     18   SWM8.S   Spring Washer M8 Zinc   4     19   SS825.S   Hex Head Set Screw M8 X 25 Zinc   7     20   CMX135-20   Handle   1     21   CMX135-20   Handle Grip Ø32   2     22   FWM12.S   Flat Washer M12 Zinc   1     23   SWM12.S   Spring Washer M12 Zinc   1     24   SS1230.S   Hex Head Set Screw M12 X 30 Zinc   1     25   CMX135-25   Self-Tapping Screw ST4.2x16   7     26   CMX135-26   Motor End Plate   1     27   CMX135-27   Motor Seat   1     28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-30   Motor (for CMX135 only)   1     30   CMX135-31   Adjusting Was  | 11   | CMX135-11  | Leather Washer Ø6                | 6   |
| 14     SS620.S     Hex Head Set Screw M6 X 20 Zinc     2       15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CM   | 12   | CMX135-12  | Cogwheel (Large)                 | 1   |
| 15     CMX135-15     Plastic Rotator     1       16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-32     Bearing 6305-2RS <td>13</td> <td>SS625.S</td> <td>Hex Head Set Screw M6 X 25 Zinc</td> <td>6</td>       | 13   | SS625.S    | Hex Head Set Screw M6 X 25 Zinc  | 6   |
| 16     NLN8.S     Nyloc Nut M8 Zinc     6       17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS </td <td>14</td> <td>SS620.S</td> <td>Hex Head Set Screw M6 X 20 Zinc</td> <td>2</td> | 14   | SS620.S    | Hex Head Set Screw M6 X 20 Zinc  | 2   |
| 17     FWM8.S     Flat Washer M8 Zinc     8       18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1   | 15   | CMX135-15  | Plastic Rotator                  | 1   |
| 18     SWM8.S     Spring Washer M8 Zinc     4       19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1   | 16   | NLN8.S     | Nyloc Nut M8 Zinc                | 6   |
| 19     SS825.S     Hex Head Set Screw M8 X 25 Zinc     7       20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1   | 17   | FWM8.S     | Flat Washer M8 Zinc              | 8   |
| 20     CMX135-20     Handle     1       21     CMX135-21     Handle Grip Ø32     2       22     FWM12.S     Flat Washer M12 Zinc     1       23     SWM12.S     Spring Washer M12 Zinc     1       24     SS1230.S     Hex Head Set Screw M12 X 30 Zinc     1       25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1  | 18   | SWM8.S     | Spring Washer M8 Zinc            | 4   |
| 21   CMX135-21   Handle Grip Ø32   2     22   FWM12.S   Flat Washer M12 Zinc   1     23   SWM12.S   Spring Washer M12 Zinc   1     24   SS1230.S   Hex Head Set Screw M12 X 30 Zinc   1     25   CMX135-25   Self-Tapping Screw ST4.2x16   7     26   CMX135-26   Motor End Plate   1     27   CMX135-27   Motor Seat   1     28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1  | 19   | SS825.S    | Hex Head Set Screw M8 X 25 Zinc  | 7   |
| 22   FWM12.S   Flat Washer M12 Zinc   1     23   SWM12.S   Spring Washer M12 Zinc   1     24   SS1230.S   Hex Head Set Screw M12 X 30 Zinc   1     25   CMX135-25   Self-Tapping Screw ST4.2x16   7     26   CMX135-26   Motor End Plate   1     27   CMX135-27   Motor Seat   1     28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1   | 20   | CMX135-20  | Handle                           | 1   |
| 23   SWM12.S   Spring Washer M12 Zinc   1     24   SS1230.S   Hex Head Set Screw M12 X 30 Zinc   1     25   CMX135-25   Self-Tapping Screw ST4.2x16   7     26   CMX135-26   Motor End Plate   1     27   CMX135-27   Motor Seat   1     28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1   | 21   | CMX135-21  | Handle Grip Ø32                  | 2   |
| 24 SS1230.S Hex Head Set Screw M12 X 30 Zinc 1   25 CMX135-25 Self-Tapping Screw ST4.2x16 7   26 CMX135-26 Motor End Plate 1   27 CMX135-27 Motor Seat 1   28 SS830.S Hex Head Set Screw M8 X 30 Zinc 2   29 CMX135-29 Toothed Belt (6PJ-L540) 1   30 CMX135-30 Motor (for CMX135 only) 1   31 CMX135-31 Adjusting Washer 2   32 CMX135-32 Bearing 6305-2RS 1   | 22   | FWM12.S    | Flat Washer M12 Zinc             | 1   |
| 25     CMX135-25     Self-Tapping Screw ST4.2x16     7       26     CMX135-26     Motor End Plate     1       27     CMX135-27     Motor Seat     1       28     SS830.S     Hex Head Set Screw M8 X 30 Zinc     2       29     CMX135-29     Toothed Belt (6PJ-L540)     1       30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1  | 23   | SWM12.S    | Spring Washer M12 Zinc           | 1   |
| 26   CMX135-26   Motor End Plate   1     27   CMX135-27   Motor Seat   1     28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1   | 24   | SS1230.S   | Hex Head Set Screw M12 X 30 Zinc | 1   |
| 27   CMX135-27   Motor Seat   1     28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1  | 25   | CMX135-25  | Self-Tapping Screw ST4.2x16      | 7   |
| 28   SS830.S   Hex Head Set Screw M8 X 30 Zinc   2     29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1  | 26   | CMX135-26  | Motor End Plate                  | 1   |
| 29   CMX135-29   Toothed Belt (6PJ-L540)   1     30   CMX135-30   Motor (for CMX135 only)   1     31   CMX135-31   Adjusting Washer   2     32   CMX135-32   Bearing 6305-2RS   1   | 27   | CMX135-27  | Motor Seat                       | 1   |
| 30     CMX135-30     Motor (for CMX135 only)     1       31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1  | 28   | SS830.S    | Hex Head Set Screw M8 X 30 Zinc  | 2   |
| 31     CMX135-31     Adjusting Washer     2       32     CMX135-32     Bearing 6305-2RS     1   | 29   | CMX135-29  | Toothed Belt (6PJ-L540)          | 1   |
| 32 CMX135-32 Bearing 6305-2RS 1   | 30   | CMX135-30  | Motor (for CMX135 only)          | 1   |
|   | 31   | CMX135-31  | Adjusting Washer                 | 2   |
| 33 CMX135-33 External Circlip Ø30 1   | 32   | CMX135-32  | Bearing 6305-2RS                 | 1   |
|   | 33   | CMX135-33  | External Circlip Ø30             | 1   |

| Item | Part No.   | Description                   | Qty |
|------|------------|-------------------------------|-----|
| 34   | CMX135-34  | Bearing 6206-2RS              | 1   |
| 35   | CMX135-35  | Drum Rotating Shaft           | 1   |
| 36   | CMX135-36  | Internal Circlip Ø62          | 3   |
| 37   | CMX135-37  | External Circlip Ø15          | 1   |
| 38   | CMX135-38  | O-Ring (41.5 x 2.65)          | 1   |
| 39   | CMX135-39  | Drive Pinion                  | 1   |
| 40   | CMX135-40  | Pin 6 x 25                    | 1   |
| 41   | CMX135-41  | Drive Pinion Shaft            | 1   |
| 42   | B/6202-2RS | Bearing 6202-2rs              | 2   |
| 43   | CMX135-43  | Split Pin Ø5 x 40             | 2   |
| 44   | CMX135-44  | Flat Washer                   | 2   |
| 45   | CMX135-45  | Fixed Wheel (for CMX135 only) | 2   |
| 46   | CMX135-46  | Frame (for CMX135 only)       | 1   |
| 47   | CMX135-47  | R-Clip Ø3                     | 2   |
| 48   | CMX135-48  | Leg Connection Bracket        | 1   |
| 49   | CMX135-49  | Support Leg                   | 4   |
| 50   | CMX135-50  | Latch Pin Ø10 x 126           | 2   |
| 51   | CMX135-51  | Wire Snap Ring for Shaft      | 1   |
| 52   | CMX135-52  | Internal Circlip              | 1   |
| 53   | CMX135-53  | Bearing 61906-2RS             | 2   |
| 54   | CMX135-54  | Pulley (Large)                | 1   |
| 55   | CMX135-55  | Strain Relief Nut             | 1   |
| 56   | CMX135-56  | Strain Relief Bolt            | 1   |
| 57   | CMX135-57  | Strain Relief Locknut         | 1   |
| 58   | CMX135-58  | Plug / Plug                   | 1   |
| 59   | CMX135-59  | Self-Tapping Screw ST3.5x16   | 4   |
| 60   | CMX135-60  | Switch (On/Off)               | 1   |
| 61   | CMX135-61  | Switch Gasket (Rubber)        | 1   |
| 62   | CMX135-62  | Motor Cover                   | 1   |
| 63   | CMX135-63  | Decorative Cover              | 1   |
| 64   | CMX135-64  | Self-Tapping Screw ST4.2x13   | 2   |
| 65   | CMX135-65  | Steel Ball Pin                | 1   |
| 66   | CMX135-66  | Pin Chain                     | 11  |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 sales@sealey.co.uk www.sealey.co.uk