


## Parts Information:

## Cordless Hammer Drill/Driver 18V 1hr Charge



Item	Part No.	Description
1	CP1801V.V3-01	COVER PLATE
2	CP1801V.V3-02	REVERSE SWITCH
3, 14	CP1801V3.3+14	CASING ASS'Y
4	CP1801V.V3-04	SPEED SELECTION SWITCH KNOB
5	CP1801V.V3-05	MOTOR
6	CP1801V.V3-06	GEARBOX ASS'Y
7	DC/J-38HC	DRILL CHUCK KEYLESS 3/8" X 24 THROUGH HO
8	CP1801V.V3-08	CHUCK SCREW
11	CP1801V.V3-11	SWITCH ASS'Y
12	CP1801VBPV3	CORDLESS POWER TOOL BATTERY 18V for CP18
13	CP1801V.V3-13	RD HEAD S/T SCREW M3X20 BLACK
15	CP1801V.V3-15	LCD BATTERY INDICATOR
	CP1801V.V3-C	BATTERY CHARGER (NOT SHOWN)
		ACCESSORIES (NOT SHOWN):

Item	Part No.	Description
	CP1801V3.ACC1	MAGNETIC BIT HOLDER (NOT SHOWN)
	AK4701.02	DRILL BIT 1.5mm 'COBALT' (NOT SHOWN)
	AK4701.04	DRILL BIT 2.5mm 'COBALT' (NOT SHOWN)
	AK4701.05	DRILL BIT 3mm 'COBALT' (NOT SHOWN)
	AK4701.07	DRILL BIT 4mm 'COBALT' (NOT SHOWN)
	AK4701.09	DRILL BIT 5mm 'COBALT' (NOT SHOWN)
	AK4701.11	DRILL BIT 6mm 'COBALT' (NOT SHOWN)
	S0613.41	SLOTTED BIT 5mm CR-V 25mmL (NOT SHOWN)
	S0613.42	SLOTTED BIT 6mm CR-V 25mmL (NOT SHOWN)
	S0613.45	BIT PH1 (NOT SHOWN)
	S0613.46	BIT PH2 (NOT SHOWN)
	S0513.22	POZY BIT PZ1 (NOT SHOWN)
	S0613.49	BIT PZ2 (NOT SHOWN)
	CP1801V.BMC	BLOW MOULD CASE (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk