



Part numbers apply to both models unless otherwise noted in the description.

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	CP9918VHK/01	CHUCK SCREW - CP9918VHK	13	CP9918VHK/13	HEX NUT
1	CP2018VHK/01A	CHUCK SCREW - CP2018VHK	15	CP9918VHK/15	CASE COMPLETE - CP9918VHK
2	CP9918VHK/02	KEYLESS CHUCK, 10mm - CP9918VHK	15	CP2018VHK/15	CASE COMPLETE - CP2018VHK
2	CP2018VHK/02A	KEYLESS CHUCK, 13mm - CP2018VHK	16	CP9918VHK/16	SWITCH SPACE COVER
3	CP9918VHK/03	GEARBOX - CP9918VHK	18	CP9918VHK/18	SPRING WASHER
3	CP2018VHK/03A	GEARBOX - CP2018VHK	19	CP9918VHK/19	BODY SCREW
4	CP9918VHK/04	MOTOR SCREW - CP9918VHK	20	CP9918VHK/20	BODY SCREW
4	CP2018VHK/04	MOTOR SCREW - CP2018VHK	22	CP9918VHK/22	BODY SCREW
5	CP9918VHK/05	SPRING WASHER	23	CP9918VHK/23	HEAT SINK SCREW
6	CP9918VHK/06	MOTOR BRACKET	24	CP9918VHK/24	HEAT SINK
7	CP9918VHK/07	MOTOR GEAR - CP9918VHK	25	CP9918VHK/25	TERMINAL BRACKET
7	CP9918VHK/07	MOTOR GEAR - CP2018VHK	26	CP9918VHK/26	SWITCH BRACKET
8	CP9918VHK/08	MOTOR - CP9918VHK	27	CP9918VHK/27	SPEED CONTROL SWITCH
8	CP2018VHK/08	MOTOR - CP2018VHK	28	CP9918VHK/28	REVERSING KNOB
9	CP9918VHK/09	GEAR SELECTOR	29	CP9918VHK/29	MOTOR WIRE
10	CP9918VHK/10	TOP COVER	30	CP9918VHK/30	TERMINAL WIRE
11	CP9918VHK/11	SLOTTED BIT	31	CB18/99	BATTERY PACK
12	CP9918VHK/12	COVER	32	CP9918VHK/32	CHARGER, 1 HOUR, C/W PLUG