



| Item | Part No. | Description |
|------|--------------|--|
| 1 | CP2024VHK/01 | Back Support Housing |
| 2 | CP2024VHK/02 | Support Housing |
| 3 | CP2024VHK/03 | Back Cover Housing |
| 4 | CP2024VHK/04 | Cover Housing |
| 5 | CP2024VHK/05 | 2 Speed Gear Box And Motor Assy (Internal 24V) |
| 6 | CP2024VHK/06 | 2 Speed Switch Knob |
| 7 | CP2024VHK/07 | Level Gauge |
| 8 | CP2024VHK/08 | Fixing Screw For Handle |
| 9 | CP2024VHK/09 | Depth Rod |
| 10 | CP2024VHK/10 | 1 Hour Charger |
| 11 | CP2024VHK/11 | Sliding Block |

| Item | Part No. | Description |
|------|--------------|---------------------------|
| 16 | CP2024VHK/16 | Inner Plate,24V |
| 17 | CP2024VHK/17 | Spring |
| 18 | CP2024VHK/18 | Power Pack Buckle |
| 19 | CP2024VHK/19 | Insert |
| 20 | CP2024VHK/20 | Screw 4x16mm |
| 21 | CP2024VHK/21 | Screw 4x30mm |
| 22 | CP2024VHK/22 | Keyless Chuck 13mm W/Lock |
| 23 | CP2024VHK/23 | Screw 5x23mm |
| 24 | CB24/01 | Battery Pack |
| 25 | CP2024VHK/25 | Front Handle |
| 26 | CP2024VHK/26 | Square Nut M6x4 |
| 27 | CP2024VHK/27 | Clamp Plate |
| 28 | CP2024VHK/28 | LCD Display,3Levels |
| 29 | CP2024VHK/29 | Battery Tester Plate |
| 30 | CP2024VHK/30 | Push Button |
| 31 | CP2024VHK/31 | LCD Cover |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.