



Item	Part No.	Description
1	198.324206	Pawl Cover
2	198.704904	Pawl (Complete, Includes Spring & Support)
3	198/324204	Pawl Support
4	198.704904	Pawl (Complete, Includes Spring & Support)
5	198/704042	Slip Ring
6	198.322124	Cable Reel
7	198.162220	Wire
8	198.704913	Pivot
9	198.322127	Back Plate
10	198.705035	Backing Plate
11	198.620125	Wall Bracket
12	198.324230	Support Pin
13	198.328025	Red Cover, Right

Item	Part No.	Description
14	198.323344	Hose Stopper With Screws
15	198.322115	Spacer
16	198.328125	Red Cover, Left
17	198.324290	Cover
--	198.122325	Transformer (NOT SHOWN)
19	198/704100	Plastic Handle (Assembly)
20	198/704100	Plastic Handle (Assembly)
21	198/704100	Plastic Handle (Assembly)
22	198/322732	Switch Button
23	198/193100	Lamp Holder e27
24	198/462105	Metal Cage
--	198.704152	Complete Pivot (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.