



Item	Part No.	Description
1	120/112395	Filter card
2	120/112692	Scr
3	120/114002	Card
5	120.323101	Switch knob set
6	120.121507	Switch
7	120/122859	Thermostat
8	120/122403	Fuse holder (glass type fuse - clips in)
9	120.122913	Fuse (glass 32 mamp 250v 5x20)
10	120/132299	Mains cable
11	120.169207	Transformer
12	120/164948	Auxiliary transformer
13	120/313548	Control pcb

Item	Part No.	Description
14	120/322472	Front panel
15	120.649831	Bottom
16	120.980125	Kit, cover
17	120/712037	Dinse socket
20	120/990046	Bushing & nut, cable
21	120/722956	Mandrel, electrode holder
22	120/990240	Handle, 2 halves
23	120/122393	Microswitch
24	120/122743	Thermostat
25	120/322148	Cable bushing
26	120.742355	Brass nut
--	120.980440	Front panel + card (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.