
Thank you for purchasing a Sealey Product. Manufactured to a high standard this product will, if used according to these instructions and properly maintained, give you years of trouble free performance.

ASSEMBLY INSTRUCTIONS

- 1.1. Wheel kit for Generators HG90.44, and HG130.74.V2, - Fig.1.
- Note: All item numbers refer to the parts shown in fig.1.
- 1.1.1. Fit the wheel axle (10) to the engine end of the frame using the bolts. washers and nuts (1. 3 & 4).
- 1.1.2. Fit the wheels (8) onto the axle (10), and secure using the retaining washers (9).
- 1.1.3. Fit the front support stand (11) to the alternator end of the frame using the bolts, washers and nuts (2, 3 & 4).
- 1.1.4. Fit the handles (12) to the alternator end of the frame using the bolts, washers and nuts (13, 14 & 15).
- 1.1.5. Fit the suspension mount (5) to the front support stand and secure using the washer and nut (6 & 7).
- 1.1.6. Ensure all nuts are correctly tightened.

Gen Kit 2 - Contents List			
Item No	Description	Item No	Description
1	Bolt, M8 x 60mm (qty 2)	9	Retaining washer, Ø20mm (qty 2)
2	Bolt, M8 x 50 mm (qty 2)	10	Axle
3	Washer, Ø8mm (qty 4)	11	Front support stand
4	Nut, M8 (qty 4)	12	Handle
5	Suspension mount, M10 (qty 1)	13	Bolt, M6 x 55 mm (qty 2)
6	Washer, Ø10mm (qty 1)	14	Washer, Ø6mm (qty 4)
7	Nut, M10 (qty 1)	15	Nut, M6 (qty 2)
8	Wheel (atv 2)		



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of this equipment. WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim. INFORMATION: For a copy of our latest catalogue and promotions call us on 01284 757525 and leave your full name and address including your postcode.



POWER Sole UK Distributor, Sealey Group,



01284 757500



a 01284 703534 E-mail: sales@sealey.co.uk