



Item	Part No.	Description
1A	GSS.01A	REAR PANEL (R/S)
1L	GSS.01L	REAR PANEL (LEFT SIDE)
2E	GSS.02E	REAR PANEL
2F	GSS.02F	GABLE
3	GSS.03	ROOF PANEL
5C	GSS.05C	DOOR
9A	GSS.09A	FRONT PANEL (L/S)
9S	GSS.09S	REAR/SIDE PANEL (LEFT/RIGHT SIDE)
20A	GSS.20A	SUPPORT FOR ROOF/SIDE PANEL
20B	GSS.20B	UPPER SUPPORT (REAR PANEL)
20C	GSS.20C	LOWER SUPPORT (REAR PANEL)
21A	GSS.21A	UPPER SUPPORT (SIDE PANEL)
21B	GSS.21B	LOWER SUPPORT (SIDE PANEL)
21G	GSS.21G	LOWER SUPPORT
21H	GSS.21H	LOWER SUPPORT FOR GABLE

Item	Part No.	Description
21J	GSS.21J	UPPER SUPPORT FOR GABLE
22G	GSS.22G	UPPER SUPPORT BEAM (L/S)
22H	GSS.22H	UPPER SUPPORT BEAM (R/S)
32D	GSS.32D	MIDDLE SUPPORT (REAR PANEL)
38A	GSS.38A	MIDDLE SUPPORT (SIDE PANEL)
38B	GSS.38B	MIDDLE SUPPORT (SIDE PANEL)
41F	GSS.41F	DOOR SUPPORT BEAM (L/S)
41G	GSS.41G	DOOR SUPPORT BEAM (R/S)
50	GSS.50	END ROOF SUPPORT
B2	GSS.B2	DOOR SUPPORT
D2	GSS.D2	DOOR SUPPORT
70	GSS.70	BOLT LOCK
71	GSS.71	LOCK BRACE
72	GSS.72	ANGLE BRACE

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.