



Item	Part No.	Description
1	MINIMIG160I-01	Bottom Panel
2	MINIMIG160I-02	Socket
3	MINIMIG160I-03	Quick EU Socket
4	MINIMIG160I-04	Mig Torch (Fixed non-Live)
5	MINIMIG160I-05	Display PCB
6	MINIMIG160I-06	Potentiometer Knob
7	MINIMIG160I-07	Output Connector
8	MINIMIG160I-08	Main Control Board
9	MINIMIG160I-09	Power Cable
10	MINIMIG160I-10	Power Switch
11	MINIMIG160I-11	Fan Cover

Item	Part No.	Description
12	MINIMIG160I-12	Fan
13	MINIMIG160I-13	Door Cover
14	MINIMIG160I-14	Diaphragm
15	MINIMIG160I-15	Wire Feed Motor
16	MINIMIG160I-16	Control Box
17	MINIMIG160I-17	Reel Holder
18	MINIMIG160I-18	Machine Case
19	MINIMIG160I-19	Belt/Strap
20	MINIMIG160I-20	Door Lock
--	MINIMIG160I-21	Earth Cable/Clamp 1.4m (Not Shown)
--	MINIMIG160I-22	Electrode Holder 1.6m (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.