



| Item | Part No. | Description |
|------|---------------|--------------------------|
| 1 | 153.450001 | Complete Light Fixture |
| 2 | 153.4500001A | Stand |
| 3 | 153.4500005A | Base |
| 4 | 153.44900017A | Control Unit Support |
| 5 | 153.197030 | Complete Socket Assembly |
| 6 | 153.43800009 | Cable Holder |
| 7 | 153.43300003H | Ring Nut |
| 8 | 153.252007 | Front Wheel |
| 9 | 153.14900016 | Wheel, 148x51x12mm |
| 10 | 153.26900023 | Toothed Lock Washer |
| 11 | 153.450002 | Complete Socket Assembly |

| Item | Part No. | Description |
|------|---------------|-----------------------|
| 12 | 153.44900012 | Locking Knob |
| 13 | 153.44900014 | Support |
| 14 | 153.44900001 | Light Fixture |
| 15 | 153.44900002 | 1500W Heating Element |
| 16 | 153.44900004 | Protective Grid |
| 17 | 153.4501P001 | Control Unit |
| 18 | 153.13500005 | Timer |
| 19 | 153.1420004FV | Warning Light |
| 20 | 153.4501P002 | Control Unit Case |
| -- | 153.40100007 | Base Plug (NOT SHOWN) |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.