



Item	Part No.	Description
1	153.450001	Complete Light Fixture
2	153.4500001A	Stand
3	153.4500005A	Base
4	153.44900017A	Control Unit Support
5	153.197030	Complete Socket Assembly
6	153.43800009	Cable Holder
7	153.43300003H	Ring Nut
8	153.252007	Front Wheel
9	153.14900016	Wheel, 148x51x12mm
10	153.26900023	Toothed Lock Washer
11	153.450002	Complete Socket Assembly

Item	Part No.	Description
12	153.44900012	Locking Knob
13	153.44900014	Support
14	153.44900001	Light Fixture
15	153.44900002	1500W Heating Element
16	153.44900004	Protective Grid
17	153.4502P001	Control Unit
18	153.13500005	Timer
19	153.1420004FV	Warning Light
20	153.4502P002	Case
--	153.40100007	Base Plug (NOT SHOWN)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.