



Issue: 1
Date Issued: 051102

Item	Part No.	Description
1	MS130.V2-01	Saw Table
2	MS130.V2-02	Plastic Base
3	MS130.V2-03	Clamp Pad
4	MS130.V2-04	Washer
5	MS130.V2-05	Rubber Foot
6	MS130.V2-06	Screw
7	MS130.V2-07	Bolt
8	MS130.V2-08	Clamp Screw
9	MS130.V2-09	Clamp Frame
10	MS130.V2-10	Bolt, Plastic
11	MS130.V2-11	Clamp Shaft
12	MS130.V2-12	Nut
13	MS130.V2-13	Bolt
14	MS130.V2-14	Plastic Pointer
15	MS130.V2-15	Rocking Arm
20	MS130.V2-20	Rocking Lever Cover
21	MS130.V2-21	Rocking Lever
24	MS130.V2-24	Spring
25	MS130.V2-25	Positioning Pin
26	MS130.V2-26	Fixing Pin
27	MS130.V2-27	Connecting Screw
28	MS130.V2-28	Plastic Bolt

Item	Part No.	Description
29	MS130.V2-29	Guide Post
30	MS130.V2-30	Sliding Post
31	MS130.V2-31	Adjustable Frame
32	MS130.V2-32	Nut
33	MS130.V2-33	Baffle
34	MS130.V2-34	Bolt
36	MS130.V2-36	Positioning Ring
37	MS130.V2-37	Screw
38	MS130.V2-38	Guide Bar
39	MS130.V2-39	Ring Guide Loop
40	MS130.V2-40	Rivet
41	MS130.V2-41	Saw Blade, 14tpi
42	MS130.V2-42	Rivet
43	MS130.V2-43	Cover

Item	Part No.	Description
44	MS130.V2-44	Saw Frame Board
45	MS130.V2-45	Rivet
46	MS130.V2-46	Adjustable Nut
47	MS130.V2-47	Bolt
48	MS130.V2-48	Plastic Cover
49	MS130.V2-49	Sliding Frame
50	MS130.V2-50	Guide Bar
51	MS130.V2-51	Washer
52	MS130.V2-52	Nut
53	MS130.V2-53	Saw Handle
54	MS130.V2-54	Nut
55	MS130.V2-55	Washer
56	MS130.V2-56	Bolt
57	MS130.V2-57	Blade Pin