


PARTS LIST FOR Model MW100



ITEM	PART NO	DESCRIPTION
1	120/112017	POTENTIOMETER
2	120/122381	SWITCH
3	120/122571	THERMAL SWITCH
4	120/132075	MAINS CABLE
5	120/152006	FAN
6	120/113018	RECTIFIER
7	120/164741	FILTER INDUCTANCE
8	120/164954	INDUCTANCE
9	120/164949	TRANSFORMER
10	120/322112	CABLE BUSHING
11	120/322406	BELT BUCKLE
12	120/322407	BELT HOOK
13	120/322408	BELT
14	120/648679	CHASSIS
15	120/655013	COVER
16	120/712035	DINSE SOCKET
	120/712039	DINSE PLUG (NOT SHOWN)
17	120/990000	KIT DIODE
19	120/990017	KIT COMPLETE PCB
20	120/990014	KIT IGBT + DIODE
21	120/990328	KNOB
22	120/112694	CONDENSER
23	120/112048	RESISTOR
24	120/112342	RELAY
25	120/712001	WORK CLAMP
26	120/712091	ELECTRODE HOLDER
27	120/120303	LS/16

