


Sole U.K. Distributor, Sealey Group, Bury St. Edmunds, Suffolk. PARTS DIAGRAM FOR:

## PRESSURE WASHER Model No: PC2950





Sole U.K. Distributor, Sealey Group,


Bury St. Edmunds, Suffolk.

PARTS LIST & DIAGRAM FOR:

## PRESSURE WASHER Madel No. DC2050

Item	Part No.	Description	Item	Part No.	Description
1 2	Part of Kits A & Q Part of Kits A & Q	Screw, M5 x 25 Foot	61	Part of Kit A	Bush
3	Part of Kits A, C & Q	Screw, M4.8 x 22	62	Part of Kit A	Frame
ĕ	Part of Kit A	Plate	63	Part of Kit A & Q	Screw, M5 x 20
5	Part of Kit A	Screw, M4.8 x 16	64	Part of Kit A	Screw, M8 x 35
6	Part of Kit A	Hood	65	Part of Kit A, C & Q	Hose Reel
7	Part of Kit P	Wheel Axle	66	Part of Kit A	Lock Nut, 3/4
8 9	Part of Kit B Part of Kit B	Screw O-Ring, 15 x 2	67	Part of Kit A	Separator
10	Part of Kit B	Spring, 9.2 x 10 x 0.8	68	Part of Kit B	Nipple
11	Part of Kit B	Valve	69	Part of Kit N	Fair Lead
12	Part of Kit B	O-Ring, 5 x 2	70	Part of Kit Q	Handle
13	Part of Kit P	Wheel	71	Part of Kit Q	Support
14 15	Part of Kit P Part of Kit P	Circlip Hub Cap	72	Part of Kit Q	Elastic Strap
16	Part of Kit B	Manifold	74	Part of Kit N	Cable
1 17	Part of Kit B	Plug	75	Part of Kit M	
18	Part of Kit B	Cap	76	Part of Kit M	Conveyor
19	Part of Kit B	Ball			Screw
20	Part of Kit B	Spring	77	Part of Kit M	Washer
21 22	Part of Kit B Part of Kit B	O-Ring, 9.25 x 1.78 Valve Seat	78	Part of Kit M	Motor Fan
23	Part of Kit B	Anti-Extr. Ring	79	Part of Kit L	Stator, 230/50
24	Part of Kits B & E	O-Ring, 8.73 x 1.78	80	Part of Kit L	Rotor
25	Part of Kit B	Small Piston Bypass	81	Part of Kit L	Screw, M4 x 12
26	Part of Kit B	O-Ring, 4.48 x 1.78	82	Part of Kit L	Cable
27 28	Part of Kit B Part of Kit G	Anti-Extr. Ring Oil Seal	83	Part of Kit L	Shield
29	Part of Kit G	Packing Retain	84	Part of Kit L	Packing
30	Part of Kit G	O-Ring, 23.52 x 1.78	85 86	Part of Kit L	Ball Bearing
31	Part of Kit G	O-Ring, 11.11 x 1.78	87	Part of Kit L	Cap
32	Part of Kit E	Packing	88	Part of Kit H	Flange
33 34	Part of Kit O Part of Kit D & O	O-Ring, 12 x 2 Valve Unit	89	Part of Kit H	Roller Bearing
35	Part of Kit B	O-Ring, 15 x 2	90	Part of Kit H	Flange
36	Part of Kit D	Valve Guide	91	Part of Kit G	O-Ring, 80.6 x 2.62 Screw
37	Part of Kit D	Spring	92	Part of Kit B	
38	Part of Kit D	Cap	92	Part of Kit B Part of Kit B	O-Ring, 12.42 x 1.78
39 40	Part of Kit D Part of Kit D	Valve Seat O-Ring, 12.42 x 1.78	93		O-Ring, 14.00 x 1.78
41	Part of Kit E	Pump Head	95	Part of Kit B Part of Kit B	Valve Body By-pass
42	Part of Kit E	Screw, M6 x 35	96	Part of Kit B	Spacer
43	Part of Kit F	Socket	97		Spring
44	Part of Kit F	Gasket	98	Part of Kit B Part of Kit B	Blade
45 46	PC2950/45 Part of Kit G	Screw Screw, M6 x 30	99	Part of Kit B	Screw, M5 x 16 Nut
47	Part of Kit G	Crank Case	100	Part of Kit B	Nut
48	Part of Kit G	Connector	100	Part of Kit I	
49	Part of Kit G	Washer	I I '		O-Ring
50	Part of Kit G	Cap	102	Part of Kit I Part of Kit I	Label Control Box
51 52	Part of Kit G Part of Kit G	Oil Cap Spring			
53	Part of Kit G	Piston	104	Part of Kit I Part of Kit I	O-Ring 5.28 x 1.78 Microswitch
54	Part of Kit G	Retainer Ring	105	Part of Kit I	Joint
55	Part of Kit L	Screw, M6 x 22	107	Part of Kit I	Washer
56	PC2950/56	Support	107	Part of Kit I	
57	Part of Kit L	Washer, M4	108	Part of Kit I	Screw, M5 x 20
58 59	Part of Kit L PC2950/08	Ball Bearing	1109	Part of Kit I	Box Cover Switch
60	Part of Kit A	Clamp Rubber	111	Part of Kit I	Gasket
1		—	H '''	i ait UI NIL I	Gasker

			IVI	odei	NO	: P G 2	2930
1	Item	Part No.	Description		Item	Part No.	Description
l	112	Part of Kit I	O-Ring 37.82 x	1.78	119	Part of Kit I	Bushing
	113	Part of Kit I	Capacitor		120	Part of Kit I	Screw, M3.9 x 16
ı	114	Part of Kit I	Protector		121	Part of Kit I	Screw
	115	Part of Kit I	Faston Cover		125	Part of Kit B	O-Ring
ı	116	Part of Kit I	Gludgeon		129	Part of Kit I	Fair Lead
	117	Part of Kit I	Washer		130	Part of Kit I	Cable
	118	Part of Kit I	Trigger				
	Kit Pa	art No.	Description	Conte	nts		
ı		50/KIT A	Cover Kit			0, 61, 62, 63, 64,	
	PC295	50/KIT B	Manifold Kit			16, 17, 18, 19, 20, 6, 97, 98, 99, 100	, 21, 22, 23, 24, 25, 26, 27, 35, 68, 91, & 125
ı	PC295	50/KIT C	Cable Support Kit	3 & 65			
ı		50/KIT D	Small Valve Kit	34, 36,	37, 38, 39	9, & 40	
ı		50/KIT E	Head Kit	24, 32,			
ı	1	50/KIT F	Quick Socket Kit	43 & 44			
ı	1	50/KIT G	Crankcase Kit			6, 47, 48, 49, 50,	51, 52, 53, 54 & 90
ı		50/KIT H	Roller Bearing Kit	87, 88 8			
	PC295	50/KIT I	Control Board Kit			04, 105, 106, 107, 3, 119, 120, 121, 1	, 108, 109, 110, 111, 112, 113, 114, 129 & 130
ı	PC295	50/KIT L	Motor Kit	55, 57,	58, 79,80	, 81, 82, 83, 84, 8	35 & 86
1	PC295	50/KIT M	Conveyor Kit	75, 76,	77 & 78		
1	PC295	50/KIT N	Cable Kit	69 & 74			



1, 2, 3, 63, 65, 70, 71 & 72

33 & 34

7, 13, 14 & 15

Accessory	Kits

PC2950/KIT O

PC2950/KIT P

PC2950/KIT Q

Kit Part No.	Description	Contents
PC2950/120	Accessory Kit A	Gun with Hose
PC2950/121B	Accessory Kit B	Extension Lance
PC2950/129	Accessory Kit C	Fan Nozzle
PC2950/AK-D	Accessory Kit D	Nozzle and Bottle
PC2950/121A	Accessory Kit E	Rotary Nozzle

Small Valve Kit

Wheel Kit

Handle Kit