



Item	Part No.	Description
1	PC700.01	Dust cap button
2	PC700.02	Rear filter
3	PC700.03	Housing (right)
4	PC700.04	Housing (left)
5	PC700.05	Front cover (dust cap)
6	PC700.06	Front cover catch
7	PC700.07	Rear blower cover
8	PC700.08	On/off switch
9	PC700.09	Power cord
10	PC700.10	Spring for dust cap button
11	PC700.11	Large damping washer
12	PC700.12	Motor
13	PC700.13	Silencer
14	PC700.14	Front foam filter
15	PC700.15	Rear foam filter

Item	Part No.	Description
16	PC700.16	Screw
17	PC700.17	Rubber flap for dust cap
18	PC700.18	Washer
19	PC700.19	Filter (dust bag)
20	PC700.20	Capacitor (0.15uf)
21	PC700.21	Wire
22	PC700.22	Wire connector
--	PC700.G	Connecting tube
--	PC700.J	Adjustable carry strap
--	PC700.K	Upholstery brush
--	PC700.M	Crevice nozzle
--	PC700.N	Blower cover
--	PC700.O	Flexible hose
--	PC700.R	Blower connector

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**IMPORTANT:** No liability is accepted for incorrect use of product.

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.