



Pump Assembly - Part No: RE97.10C-40

Item	Description
1	Handle, grip
2	Handle
3	Handle, socket
4	Pin socket
5	Retaining ring
6	Pin, piston
7	Piston
8	Pump
9	Washer
10	Seal
11	Seal
12	Copper Washer
13	Pump valve assembly
16	Nut
17	Pump foot
18	Base
19	Seal
20	Reservoir
21	Filter
22	Base
23	Ball
24	Screw
25	Retaining ring
26	O-Ring
27	Release rod
63	O-Ring
64	Screw
65	O-Ring
66	Screw
67	O-Ring
68	Bearing
69	Bar



Hydraulic Spreader - Part No: RE97.10C-11

Item	Description
53	Seal
57	Seal
70	Seal




Ram Assembly - Part No: RE97.10C-41

Item	Description	Item	Description	Item	Description
31	Connection nut	42	Bushing	49	Retaining ring
34	Retaining ring	43	O-Ring	50	Cover
35	Cylinder	44	O-Ring	71	Washer
37	Screw	45	Jacket	72	Screw
38	Spring	46	Piston rod	73	Washer
39	V-Ring	47	Ring	74	Ball
40	Sealing ring	48	Protector ring	75	Screw
41	O-Ring				

Hose Assembly - Part No: RE97.10C-42

Item	Description
28	Hose
29	Coupling
30	Dust cap



NOTE: Items marked with a "*" are available as a **Repair Kit - Part No RE97.10C-RK**, which contains items, 10, 11, 12, 13, 19, 23, 26, 39, 40, 41, 43, 44, 53, 57, 63, 65, 67, & 70.

Issue: 1
Date: 060802