



ITEM	PART NO.	DESCRIPTION
1	RWH15.V2-01	RIGHT DECORATED CASING
2	RWH15.V2-02	OUTER FLANK CAP
3	RWH15.V2-03	INNER FLANK CAP
4	RWH15.V2-04	PULL SPRING
5	RWH15.V2-05	JAW TURN SHAFT
6	RWH15.V2-06	VINE CLAW
7	RWH15.V2-07	WIRE-CORE CONNECTOR
8	RWH15.V2-08	LOCKNUT
9	RWH15.V2-09	WIRE-CORE
10	RWH15.V2-10	SEALING GASKET
11	RWH15.V2-11	HOSE CONNECTOR
12	RWH15.V2-12	HANDLE SEAT
13	RWH15.V2-13	HANDLE
14	RWH15.V2-14	OUTER SHIELD
15	RWH15.V2-15	OUTER CASING
16	RWH15.V2-16	PULL RING
17	RWH15.V2-17	ALUMINIUM TUBE
18	RWH15.V2-18	SUPPORT SEAT
19	RWH15.V2-19	WATER HOSE
20	RWH15.V2-20	COILED SPRING
21	RWH15.V2-21	SEAL HOSE
22	RWH15.V2-22	GEAR PLATE

ITEM	PART NO.	DESCRIPTION
23	RWH15.V2-23	DRIVING BELT
24	RWH15.V2-24	GEAR PLATE BELT
25	RWH15.V2-25	REGULATION CAP
26	RWH15.V2-26	HOSE COLLAR LATCH
27	RWH15.V2-27	SPRING
28	RWH15.V2-28	LEFT DECK CAP
29	RWH15.V2-29	SEAL CAP
30	RWH15.V2-30	LOCATING BALL
31	RWH15.V2-31	GUIDE TRACK
32	RWH15.V2-32	ROTATION WHEEL
33	RWH15.V2-33	DRAINER CAP
34	RWH15.V2-34	ROTATION WHEEL
35	RWH15.V2-35	DRAINER CAP
36	RWH15.V2-36	SCREW COMPRESS COVER
37	RWH15.V2-37	TRANSFER BLOCK
38	RWH15.V2-38	PINION
39	RWH15.V2-39	COVER
40	RWH15.V2-40	DUPLEX SCREW
41	RWH15.V2-41	CAP
42	RWH15.V2-42	WATER HOSE
43	RWH15.V2-43	WHEEL
44	RWH15.V2-44	HOSE WHEEL CAP

