



Item	Part No.	Description
1	SAC41.01	Water Tank Cover
2	SAC41.02	Veil PVC
3	SAC41.03	Control Panel
4	SAC41.04	PCB Material Board
5	SAC41.05	Left Hand Side Casing
6	SAC41.06	Top Water Tank
7	SAC41.07	Wind Tunnel
8	SAC41.08	Metal Grill
9	SAC41.09	Plastic Outlet Grill
10	SAC41.10	Cam
11	SAC41.11	Front Panel
12	SAC41.12	Motor, Synchro Swing
13	SAC41.13	Water Level Window
14	SAC41.14	Water Level Board
15	SAC41.15	Lower Water Tank Cover
16	SAC41.16	Water Tank, Lower
17	SAC41.17	Fan
18	SDH20.V3-10	Capacitor 1.2uf cbb61 500v 50/60hz 3.5x2.5

Item	Part No.	Description
19	SAC41.19	Right Hand Side Casing
20	SAC41.20	Clip For Power Cord
21	SAC41.21	Impose Line Cap
22	SAC41.22	Motor
25	SAC41.25	EMC Filter
26	SAC41.26	Terminal Blocks
27	SAC41.27	Axle For Water Curtain
28	SAC41.28	Motor For Water Curtain
29	SAC41.29	Filter Outer Grill
30	SAC41.30	Water Curtain
31	SAC41.31	Rear Casing
32	SAC41.32	Transformer
33	SAC41.33	PTC
34	SAC41.34	Castor, Vertical (8mm Push Fit) 40x39x8
35	SAC41.35	Ice Box
36	SAC41.36	Drawer
--	SAC41.37	Remote Control (NOT SHOWN)
--	SAC41.F	Carbon Filter (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.