


Parts Information:

Mechanic's Utility Seat & Step Stool **Model No: SCR16**



Item	Part No.	Description
1	SCR16.01	Base Frame
2	SCR16.02	Step Plate
3	SCR16.03	Bolt M6 x 16mm
5	SCR16.05	Bolt M6 x 40mm
6	SCR16.06	Bolt M6
7	SCR16.07	Connection, 'U' Shape
8	SCR16.08	Bolt M6 x 16mm
9	SCR16.09	Seat Cushion
10	SCR16.10	Connection Plate
12	SCR16.12	Support Frame
13	SCR16.13	Plastic Cap
14	SCR16.14	Nut, Domed M8

Item	Part No.	Description
16	SCR16.16	Bolt M8 x 60mm
17	SCR16.17	Plastic Tray
18	SCR16.18	Adjustable Leg
19	SN8.S	Steel Nut M8
20	SCR16.20	Rubber Bushing A
21	SCR75.N	Nut, Castor Wheel
23	SCR16.23	Wheel, Swivel Castor
24	SCR16.24	Rubber Bushing B
	SCR16.04	Flat Washer (Not Shown)
	SCR16.15	Flat Washer (Not Shown)
	FWM10.S	Flat Washer M10 Zinc (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk

Page 1 of 1 SCR16 Issue 3 PL 22/11/21