




Parts Information:
Desk Fan 3-Speed 12" Push-Button 230V
Model No: SDF12W



Item	Part No.	Description
1	SDF12W.01	BOTTOM PAD
2	SDF12W.02	SCREW
3	SDF12W.03	FAN BASE LOWER
4	SDF12W.04	POWER CORD
5	SDF12W.05	POWER CORD COVER
6	SDF12W.06	CLIP
7	SDF12W.07	MOTOR COVER
8	SDF16W.08	MOTOR KNOB
9	SDF12W.09	MOTOR
10	SDF12W.10	MOTOR COVER
11	SDF12W.11	REAR GUARD
12	SDF16W.12	NUT FOR GUARD
14	SDF12W.14	FAN BLADE c/w NUT

Item	Part No.	Description
15	SDF12W.15	FRONT GUARD
16	SDF12W.16	GRILL GUARD DISC
17	SDF12W.17	POLE
18	SDF12W.18	ARM
19	SDF12W.19	SPRING
20	SDF12W.20	SPRING BALL
21	SDF12W.21	SPRING
22	SDF12W.22	ORIENTATION PAD
23	SDF12W.23	SWITCH
24	SDF12W.24	NUT
25	SDF12W.25	NUT COVER
26	SDF12W.26	FAN BASE UPPER
27	SDF12W.27	BOTTOM BOARD

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk